



**115W/130W
150W/175W/200W
L130W/L150W/L200W
P150W/P175W/P200W
OWNER'S MANUAL**

**READ THIS MANUAL
CAREFULLY**

U.S.A. Edition

YAMAHA MOTOR CORPORATION, U.S.A.

LIT-18626-02-91 ●





YAMAHA

**OUTBOARD MOTOR WARRANTY REGISTRATION
ENREGISTREMENT DE LA GARANTIE DU MOTEUR HORS-BORD**

Please complete and mail this card. This information is necessary to accurately register your unit for warranty.
Veuillez signer ci-dessous pour attester que le montage et l'inspection ont été faits dans le respect des directives d'inspection et que la marche à suivre pour la garantie et l'entretien a été expliquée à l'acheteur au détail.

OUTBOARD MOTOR MODEL AND SERIAL NUMBER (From I.D. label on clamp bracket)

MODÈLE ET NO. DE SÉRIE DU MOTEUR HORS-BORD (sur l'étiquette d'identification de la presse de fixation)



(For Dealer Use Only)

(A l'usage du concessionnaire)

**YAMAHA DEALER NUMBER
NO. DU CONCESSIONNAIRE
YAMAHA**

**DEALER NAME
NOM DU
CONCESSIONNAIRE**

DATE SOLD

DATE DE
LIVRAISON

OWNER'S NAME

NOM DU
PROPRIÉTAIRE

ADDRESS

ADRESSE

USAGE

(Check One)

UTILISATION

(En cochant un.)

PLEASURE

LOISIR

COMMERCIAL

COMMERCIAL

MONTH DAY YEAR

MOIS JOUR ANNÉE

FIRST

PRÉNOM

LAST

NOM DE FAMILLE

STREET

RUE

CITY

VILLE

STATE/PROVINCE

PROVINCE

ZIP

CODE POSTAL

PHONE NUMBER ()

NUMÉRO DE TÉLÉPHONE

PLACE
POSTAGE
HERE

ATTN: WARRANTY DEPARTMENT

TO THE OWNER

Thank you for choosing a Yamaha outboard motor. This Owner's Manual contains information needed for proper operation, maintenance and care. A thorough understanding of these simple instructions will help you obtain maximum enjoyment from your new Yamaha.

If you have any question about the operation or maintenance of your outboard motor, please consult a Yamaha dealer.

In this Owner's Manual particularly important information is distinguished in the following ways.



The Safety Alert Symbol means
ATTENTION! BECOME ALERT!
YOUR SAFETY IS INVOLVED!

WARNING

Failure to follow WARNING instructions could result in severe injury or death to the machine operator, a bystander, or a person inspecting or repairing the outboard motor.

CAUTION

A CAUTION indicates special precautions that must be taken to avoid damage to the outboard motor.

NOTE:

A NOTE provides key information to make procedures easier or clearer.

* Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your machine and this manual. If there is any question concerning this manual, please consult your Yamaha dealer.

Yamaha Motor Co., Ltd.

EMA10010


**115W/130W/L130W/150W/L150W
P150W/175W/P175W/200W
L200W/P200W
OWNER'S MANUAL
©1997 by Yamaha Motor Co., Ltd.
1st Edition, March 1997
All rights reserved. Any reprinting or
unauthorized use without the written
permission of Yamaha Motor Corporation,
U.S.A. is expressly prohibited.
Printed in Japan
P/N LIT-18626-02-91**

CONTENTS


E



GENERAL INFORMATION

1

BASIC COMPONENTS

2

OPERATION

3

MAINTENANCE

4


TROUBLE RECOVERY

5

INDEX

6

**READ THIS OWNER'S MANUAL CAREFULLY
BEFORE OPERATING YOUR OUTBOARD MOTOR.**



Chapter 1

GENERAL INFORMATION

1


IDENTIFICATION NUMBERS	
RECORD	1-1
EMISSION CONTROL INFORMATION...	1-2
SAFETY INFORMATION.....	1-3
IMPORTANT BOATING LABELS	1-5
BASIC BOATING RULES	1-6
FUELING INSTRUCTIONS.....	1-10
Gasoline (petrol)	1-10
Engine oil.....	1-11
BATTERY REQUIREMENT.....	1-12
PROPELLER SELECTION	1-12



EMB10010

IDENTIFICATION NUMBERS RECORD

OUTBOARD MOTOR SERIAL NUMBER



YAMAHA																			
YAMAHA MOTER CO., LTD.																			
MADE IN JAPAN																			
PAYS D'ORIGINE JAPON																			


The outboard motor serial number is stamped on the label attached to the port side of the clamp-bracket. (2-hp model: attached the upper part of the swivel bracket.)

Record your outboard motor serial number in the spaces provided to assist you in ordering spare parts from your Yamaha dealer or for reference in case your outboard motor is stolen.

KEY NUMBER



(If main key switch is equipped)

--	--	--



Your key identification number is stamped on your key as shown in the illustration. Record this number in the space provided for reference if you need a new key.

- ① Outboard motor serial number
- ② (2-hp model: outboard motor serial number)
- ③ Key number

**E****V4****V6**

EMA01010

EMISSION CONTROL INFORMATION

This engine conforms to 1998 US Environment Protection Agency (EPA) regulation for marine SI engines.

Approval label of emission control certificate

This label is attached to the bottom cowling.

①

EMISSION CONTROL INFORMATION	
ENGINE FAMILY : SYMMX	
THIS ENGINE CONFORMS TO 1998 U.S. EPA REGULATIONS FOR MARINE SI ENGINES.	
FELs : g/kw-hr	IDLE SPEED : rpm IN NEUTRAL
SPARK PLUG :	SPARK PLUG GAP (mm) :
YAMAHA MOTOR CO.,LTD.	

Existing Technology ; N/A

Manufactured date label

This label is attached to the clamp bracket or the swivel bracket.

②

YAMAHA					
Manufactured: <table border="1"><tr><td> </td><td> </td><td> </td><td> </td><td> </td></tr></table>					



EMB20010



SAFETY INFORMATION

- Before mounting or operating the outboard motor, read this entire manual. Reading it should give you an understanding of the motor and its operation.
- Before operating the boat, read any owner's or operator's manuals supplied with it and all labels. Be sure you understand each item before operating.
- Do not overpower the boat with this outboard motor. Overpowering the boat could result in loss of control. The rated power of the outboard should be equal to or less than the rated horsepower capacity of the boat. If the rated horsepower capacity of the boat is unknown, consult the dealer or boat manufacturer.
- Do not modify the outboard. Modifications could make the motor unfit or unsafe to use.
- Never operate after drinking alcohol or taking drugs.
About 50% of all boating fatalities involve intoxication.
- Have an approved personal flotation device (PFD) on board for every occupant. It is a good idea to wear a PFD whenever boating. At a minimum, children and non-swimmers should always wear PFDs, and everyone should wear PFDs when there are potentially hazardous boating conditions.
- Gasoline is highly flammable, and its vapors are flammable and explosive. Handle and store gasoline carefully. Make sure there are no gas fumes or leaking fuel before starting the engine.
- Check throttle, shift, and steering for proper operation before starting the engine.
- Attach the engine stop switch lanyard to a secure place on your clothing, or your arm or leg while operating. If you accidentally leave the helm, the lanyard will pull from the switch, stopping the engine.
- Know the marine laws and regulations where you will be boating — and obey them. Refer to "BASIC BOATING RULES" in the chapter.
- Stay informed about the weather. Check weather forecasts before boating. Avoid boating in hazardous weather.
- Tell someone where you are going: leave a Float Plan with a responsible person. Be sure to cancel the Float Plan when you return.
- Use common sense and good judgment when boating. Know your abilities, and be sure you understand how your boat handles under the different boating conditions you may encounter. Operate within your limits, and the limits of your boat. Always operate at safe speeds, and keep a careful watch for obstacles and other traffic.
- Always watch carefully for swimmers during the engine operation.
- Stay away from swimming areas.
- When a swimmer is in the water near you shift into neutral and shut off the engine.



- Be informed about boating safety. Additional publications and information can be obtained from many organizations, including the following:

United States Coast Guard

Consumer Affairs Staff (G-BC)
Office of Boating, Public, and Consumer
Affairs
U.S. Coast Guard Headquarters
Washington, D.C. 20593-0001
Boating Safety Hotline: 1-800-368-5647

**National Marine Manufacturers
Association (NMMA)**

401 N. Michigan Ave.
Chicago, IL 60611

Marine Retailers Association of America

155 N. Michigan Ave.
Chicago, IL 60601




Location



EMB30010

IMPORTANT LABELS

V4



V6



WARNING LABELS

①

 WARNING

- Be sure shift control is in neutral before starting engine. (except 2HP)
- Do not touch or remove electrical parts when starting or during operation.
- Keep hands, hair, and clothes away from flywheel and other rotating parts while engine is running.

YAMAHA

6A1-83625-41

② **Counter rotation model** **WARNING**

Use only a counterclockwise rotation propeller with this engine. Counterclockwise propellers are marked with a letter "L" after the size indication.

The wrong type of propeller could cause the boat to go in an unexpected direction, which could lead to an accident.

YAMAHA

6A1-83625-41

③

YAMAHA OIL TANK
CAPACITY: 10.5 LITERS
11.1 U.S. qt.
9.2 IMP. qt.**ENGINE OIL ONLY**

- Pour the engine oil into the oil tank, not gasoline.

RECOMMENDED OIL:

YAMALUBE 2 STROKE OUTBOARD OIL or an equivalent TC-W3 certified outboard oil.

 WARNING

- Fire or explosion could result.
- Do not add gasoline to the oil tank.

YAMAHA

RE-13407-03



EMB40010

BASIC BOATING RULES (Rules of the road)

Just as there are rules which apply when you are driving on streets and high ways, there are waterway rules which apply when you are driving your boat. These rules are used internationally, and are also enforced by the United States Coast Guard and local agencies. You should be aware of these rules, and follow them whenever you encounter another vessel on the water.

Several sets of rules prevail according to geographic location, but are all basically the same as the International Rules of the Road. The rules presented here in your Owner's Manual are condensed, and have been provided for your convenience only. Consult your local U.S. Coast Guard Auxiliary or Department of Motor Vehicles for a complete set of rules governing the waters in which you will be using your boat.

STEERING AND SAILING RULES AND SOUND SIGNALS

Whenever two vessels on the water meet one another, one vessel has the right-of-way; it is called the "stand-on" vessel. The vessel which does not have the right-of-way is called the "give-way" or "burdened" vessel. These rules determine which vessel has the right-of-way, and what each vessel should do.

Stand-on Vessel

The vessel with the right-of-way has the duty to continue its course and speed, except to avoid an immediate collision. When you maintain your direction and speed, the other vessel will be able to determine how best to avoid you.

Give-way Vessel

The vessel which does not have the right-of-way has the duty to take positive and timely action to stay out of the way of the Stand-On vessel. Normally, you should not cross in front of the vessel with the right-of-way. You should slow down or change directions briefly and pass behind the other vessel. You should always move in such a way that the operator of the other vessel can see what you are doing.

"The general prudential rule"

This rule is called Rule 2 in the International Rules and says,

'In obeying and construing these rules due regard shall be had to all dangers of navigation and collision, and to any special circumstances, which may render a departure from the above rules necessary in order to avoid immediate danger.'

In other words, follow the standard rules except when a collision will occur unless both vessels try to avoid each other. If that is the case, both vessels become "Give-Way" vessels.



RULES WHEN ENCOUNTERING VESSELS

There are three main situations which you may encounter with other vessels which could lead to a collision unless the Steering Rules are followed:

Meeting

(you are approaching another vessel head-on)


Crossing

(you are travelling across the other vessel's path)

Overtaking

(you are passing or being passed by another vessel)


In the following illustration, your boat is in the center. You should give the right-of-way to any vessels shown in white area (you are the Give-Way vessel). Any vessels in the shaded area must yield to you (they are the Give-Way vessels). Both you and the meeting vessel must alter course to avoid each other.



Meeting


If you are meeting another power vessel head on, and are close enough to run the risk of collision, neither of you has the right-of-way! Both of you should alter course to avoid an accident. You should keep the

other vessel on your port (left) side. This rule doesn't apply if both of you will clear one another if you continue on your set course and speed.



Crossing

When two power driven vessels are crossing each other's path close enough to run the risk of collision, the vessel which has the other on the starboard (right) side must keep out of the way of the other. If the other vessel is on your right, you must keep out of its way; you are the Give-Way vessel. If the other vessel is on your port (left) side, remember that you should maintain course and direction, provided the other vessel gives you the right-of-way as it should.



Overtaking

If you are passing another vessel, you are the "Give-Way" vessel. This means that the other vessel is expected to maintain its



course and speed. You must stay out of its way until you are clear of it. Likewise, if another vessel is passing you, you should maintain your speed and direction so that the other vessel can steer itself around you.

OTHER SPECIAL SITUATIONS

There are three other rules you should be aware of when driving your boat around other vessels.

Narrow Channels and Bends

When navigating in narrow channels, you should keep to the right when it is safe and practical to do so. If the operator of a power-driven vessel is preparing to go around a bend that may obstruct the view of other water vessels, the operator should sound a prolonged blast on the whistle (4 to 6 seconds). If another vessel is around the bend, it too should sound the whistle. Even if no reply is heard, however, the vessel should still proceed around the bend with caution. If you navigate such waters with your boat, you will need to carry a portable air horn, available from local marine supply stores.

Fishing Vessel Right-of-way

All vessels which are fishing with nets, lines or trawls are considered to be "fishing vessels" under the International Rules. Vessels with trolling lines are not considered fishing vessels. Fishing vessels have the right-of-way regardless of position. Fishing vessels cannot, however, impede the passage of other vessels in narrow channels.

Sailing Vessel Right-of-way

Sailing vessels should normally be given the right-of-way. The exceptions to this are:

1. When the sailing vessel is overtaking

the power-driven vessel, the power-driven vessel has the right-of-way.

2. Sailing vessels should keep clear of any fishing vessel.
3. In a narrow channel, a sailing vessel should not hamper the safe passage of a power-driven vessel which can navigate only in such a channel.


Reading Buoys and Other Markers

The waters of the United States are marked for safe navigation by the lateral system of buoyage. Simply put, buoys and markers have an arrangement of shapes, colors, numbers and lights to show which side of the buoy a boater should pass on when navigating in a particular direction. The markings on these buoys are oriented from the perspective of being entered from seaward (the boater is going towards the port). This means that red buoys are passed on the starboard (right) side when proceeding from open water into port, and black buoys are to port (left) side. When navigating out of port, your position with respect to the buoys should be reversed; red buoys should be to port and black buoys to starboard.

Many bodies of water used by boaters are entirely within the boundaries of a particular state. The Uniform State Waterway Marking System has been devised for these waters. This system uses buoys and signs with distinctive shapes and colors to show regulatory or advisory information. These markers are white with black letters and orange borders. They signify speed zones, restricted areas, danger areas, and general information.



Remember, markings may vary by geographic location. Always consult local boating authorities before driving your boat in unfamiliar waters.





EMB50010

FUELING INSTRUCTIONS

⚠ WARNING

GASOLINE AND ITS VAPORS ARE HIGHLY FLAMMABLE AND EXPLOSIVE!

- Do not smoke when refueling, and keep away from sparks, flames, or other sources of ignition.
- Stop engine before refueling.
- Refuel in a well-ventilated area. Refuel portable fuel tanks off the boat.
- Take care not to spill gasoline. If gasoline spills, wipe it up immediately with dry rags.
- Do not overfill the fuel tank.
- Tighten the filler cap securely after refueling.
- If you should swallow some gasoline inhale a lot of gasoline vapor, or get gasoline in your eyes, get immediate medical attention.
- If any gasoline spills onto your skin, immediately wash with soap and water. Change clothing if gasoline spills on it.
- Touch the fuel nozzle to the filler opening or funnel to help prevent electrostatic sparks.

GASOLINE (PETROL)

Recommended gasoline:

Regular unleaded gasoline with a minimum octane rating of 86
(Pump octane number): $(R+M)/2$

If knocking or pinging occurs, use a different brand of gasoline or premium unleaded fuel. Unleaded fuel will give you longer spark plug life and reduced maintenance cost. If unleaded gasoline is not available, then leaded regular gasoline can be used.



Gasohol

There are two types of gasohol: gasohol containing ethanol and that containing methanol. Gasohol containing ethanol can be used if ethanol content does not exceed 10% and the fuel meets minimum octane ratings. Gasohol containing methanol is not recommended by Yamaha because it can cause fuel system damage or engine performance problems.

CAUTION:

Use only new clean gasoline which has been stored in clean containers and is not contaminated with water or foreign matter.

EMBS2010

ENGINE OIL

Recommended oil:

YAMALUBE 2 STROKE OUTBOARD OIL

If YAMALUBE 2 STROKE OUTBOARD OIL is not available, another 2-stroke engine oil with a BIA-certified TC-W3 rating may be used.



EMB70010

BATTERY REQUIREMENT (for Electric start model)

Choose battery which meets the following specifications.

Battery capacity:

Minimum cold crank performance

380 Amps at -17.8°C (0°F)

Minimum reserve capacity

124 minutes at 26.7°C (80°F)

CAUTION



Do not use the battery that does not meet the specified capacity. If different battery from the specification is used, the electric system may perform poorly or be overloaded, causing electrical system damage.

EMB80011

PROPELLER SELECTION

The performance of your outboard motor will be critically affected by your choice of propeller, for an incorrect one could adversely affect performance and could seriously damage the motor. The engine speed depends on the propeller size and the boat load. If the engine speed is too high or too low for good engine performance, this will have an adverse effect on the engine.

Yamaha outboard motors are fitted with propellers chosen to perform well over a range of applications, but there may be uses where a propeller with a different pitch would be better. For a greater operating load, a smaller-pitch propeller is more suitable as it enables the correct engine speed to be maintained. Conversely, a larger-pitch propeller is more suitable for a smaller operating load.



Yamaha dealers stock a range of propellers, and can advise you and install a propeller on your outboard that is best suited to your application.



NOTE:

Select a propeller which will allow the engine to reach the middle or upper half of the operating range at full throttle with the maximum boat load. If operating conditions such as light boat loads then allow the engine rpm to rise above the maximum recommended range, reduce the throttle setting to maintain the engine in the proper operating range.

Recommended full throttle operating range; Refer to SPECIFICATIONS, Page 4-1.

- ① Propeller diameter (in inches)
- ② Propeller pitch (in inches)
- ③ Type of propeller (Propeller mark)

Propeller removal and installation; Refer to propeller checking section in Chapter 4.



EMC00010

Chapter 2

BASIC COMPONENTS

MAIN COMPONENTS.....2-1

OPERATIONS OF CONTROLS AND
OTHER FUNCTIONS2-3

Start-in-gear protection2-3

Choke knob2-3

Remote control2-4

Trim tab2-10

Power trim and tilt switch2-11

Digital tachometer.....2-12

Digital speedometer.....2-13

Fuel management meter2-16

Tilt support lever2-20

Top cowling lock levers2-20

Top cowling release lever2-21

WARNING SYSTEM.....2-22


Overheat warning system2-22

Oil level warning/Oil filter clogging
warning.....2-23




EMC10010

MAIN COMPONENTS









- | | |
|--|---|
| ① Power trim and tilt switch | ⑬ Top cowling |
| *4 ② Flushing device | ⑭ Cooling water pilot hole |
| ③ Tilt support lever | ⑮ Remote control box (Side mount type) |
| ④ Anti-cavitation plate | *3 ⑯ Remote control box (Binnacle mount type) |
| ⑤ Trim tab (Anode) | *3 ⑰ Switch panel (Together with ⑯) |
| ⑥ Propeller | ⑱ Digital tachometer |
| ⑦ Cooling water inlet | ⑲ Digital speedmeter |
| ⑧ Anode | ⑳ Remote oil tank |
| ⑨ Clamp bracket | |
| ⑩ Power trim and tilt unit | |
| ⑪ Cowling release lever*1/
Cowling lock lever*2 | |
| ⑫ Choke knob | |
- *1.V4
*2.V6
*3.Counter rotation model
*4.SWS



EMC10010



MAIN COMPONENTS

P150/P175/P200



- ① Power trim and tilt switch
- ② Flushing device
- ③ Tilt support lever
- ④ Anti-cavitation plate
- ⑤ Trim tab (Anode)
- ⑥ Propeller
- ⑦ Cooling water inlet
- ⑧ Anode
- ⑨ Clamp bracket

- ⑩ Power trim and tilt unit
- ⑪ Cowling lock lever
- ⑫ Choke knob
- ⑬ Top cowling
- ⑭ Cooling water pilot hole
- ⑮ Remote control box (Side mount type)
- ⑯ Digital tachometer
- ⑰ Digital speedometer
- ⑱ Remote oil tank



EMC20010



OPERATIONS OF CONTROLS AND OTHER FUNCTIONS

EMC23110

START-IN-GEAR PROTECTION

This feature permits the engine to be started only when it is Neutral. Always select Neutral before attempting to start the engine.

- ① Start-in-gear protection device
(neutral switch)




EMC42010

CHOKE KNOB

Pulling out this knob (setting it to ON) supplies a rich mixture required to start the engine.

NOTE:

The choke knob for remote control model has the same function as the choke switch on the remote control box.




EMC80212*


REMOTE CONTROL



Both the shifter and the throttle are actuated by the remote control lever. In addition, this remote control also has the electrical switches.

- A** Side mount remote control box
- B** Binnacle mount remote control box
- C** Switch panel (Together with **B**)



- ① Remote control lever
- ② Neutral interlock trigger
- ③ Neutral throttle lever
- ④ Free accelerator
- ⑤ Main switch/Choke switch
- ⑥ Engine stop lanyard switch
- ⑦ Power trim and tilt switch
- ⑧ Throttle friction adjusting screw







EMC50010*

Remote control lever

Moving the lever forward from the Neutral position engages Forward gear. Pulling the lever back from Neutral engages Reverse. The engine will continue to run at idle until the lever is moved about 35° (a detent can be felt). Moving the lever farther opens the throttle, and the engine will begin to accelerate.



- ① Neutral
- ② Forward
- ③ Reverse
- ④ Shift
- ⑤ Fully closed
- ⑥ Throttle
- ⑦ Fully open



EMC50110

Neutral interlock trigger

To shift out of Neutral, the neutral interlock trigger of the remote control lever must first be pulled up.


EMC50210

Neutral throttle lever



To open the throttle without shifting into either Forward or Reverse, place the remote control lever in the Neutral position and lift the neutral throttle lever.

NOTE:

The neutral throttle lever will operate only when the remote control lever is in Neutral. The remote control lever will operate only when the neutral throttle lever is in the closed position.



- ① Fully open
- ② Fully closed



EMC48110

Main switch

The main switch controls the ignition system; its operation is described below.

• OFF



Electrical circuits switched off.
(The key can be removed.)

• ON

Electrical circuits switched on.
(The key cannot be removed.)

• START


Starter-motor will turn and start engine.
(When the key is released, it returns automatically to "ON".)




EMC50310

Choke switch

While the main switch is being pressed in at "ON" or "START", the choke system will switch on, to supply a rich mixture required to start the engine. (When the key is released, it will switch off automatically.)







EMC28210

Engine stop lanyard switch

The lock-plate on the end of the lanyard must be attached to the engine stop switch for the engine to run. The lanyard should be attached to a secure place on the operator's clothing, or arm or leg. Should the operator fall overboard or leave the helm, the lanyard will pull out the lock plate, stopping ignition to the engine. This will prevent the boat from running away under power.




⚠ WARNING

- Attach the engine stop switch lanyard to a secure place on your clothing, your arm or leg while operating.
- Do not attach the lanyard to clothing that could tear loose. Do not route the lanyard in such a way that it could become entangled, preventing it from functioning.
- Avoid accidentally pulling the lanyard during normal operation. Loss of engine power means the loss of most steering control. Also, without engine power, the boat could slow rapidly. This could cause people and objects in the boat to be thrown forward.

**NOTE:**

The engine cannot be started with the lock-plate removed.

- ① Lock-plate
- ② Lanyard



EMD20510

Power trim and tilt switches


The power trim and tilt adjusts the motor angle in relation to the transom. The power trim and tilt switch is located on the remote control lever grip. Individual-engine switches are also on the control cover. Pushing the switch UP trims the motor up, then tilts the motor up. Pressing the switch DOWN tilts the motor down and trims the motor down. When the switch button is released, the motor will stop in its current position.

NOTE:

On the dual engine control, the switch on the remote control grip controls both engines at the same time.

⚠ WARNING

Excessive trim for the operating conditions (either trim up or down) can cause boat instability and can make steering the boat more difficult. This increases the possibility of an accident. If the boat begins to feel unstable or is hard to steer, slow down and/or readjust the trim angle.



- ① Fully-open
- ② Fully-closed
- ③ Free accelerator


EMC81110

Free accelerator

To open the throttle without shifting into either Forward or Reverse, push the free accelerator button and turn the remote control lever.

NOTE:

- The free accelerator button can be operated only when the remote control lever is in the Neutral position.
- After the button is pushed, the remote control lever must be moved at least 35° to begin opening the throttle.
- After operating the free accelerator, return the remote control lever to the Neutral position. The free accelerator button will return automatically to its set position. The remote control will then engage Forward and Reverse normally.




EMC87011

Throttle friction adjusting screw

A friction device in the remote control box provides resistance to movement of the remote control lever.

This is adjustable for operator preference. An adjusting screw is located at the front of the remote control box.


Resistance	Screw
Increase	Turn clockwise
Decrease	Turn counterclockwise



⚠ WARNING

Do not overtighten the friction adjusting screw.

If there is too much resistance, it may be difficult to move the lever, which could result in an accident.




EMD04011*

TRIM TAB


The trim tab should be adjusted so that the steering control can be turned to either the right or left by applying the same amount of force.

⚠ WARNING

An improperly adjusted trim tab may cause difficult steering. Always test run after the trim tab has been installed or replaced to be sure steering is correct. Be sure you have tightened the bolt after adjusting the trim tab.



- ① Trim tab
- ② Bolt
- ③ Cap




Boat tends to veer	The rear end of trim tab
To the left (port side)	Turn the left(port side), "A" in the figure
To the right (starboard side)	Turn the right (starboard side), "B" in the figure

CAUTION

The trim tab also serves as an anode to protect the engine from electrochemical corrosion.

Never paint the trim tab as it will become ineffective as an anode.




EMD20010



POWER TRIM AND TILT SWITCH

The power trim and tilt adjusts the motor angle in relation to the transom. The power trim and tilt switch is located on the port side of the bottom engine cowling. Pushing the switch UP trims the motor up, then tilts the motor up. Pressing the switch DOWN tilts the motor down and trims the motor down. When the switch button is released, the motor will stop in its current position.

⚠ WARNING

Excessive trim for the operating conditions (either trim up or down) can cause boat instability and can make steering the boat more difficult. This increases the possibility of an accident. If the boat begins to feel unstable or is hard to steer, slow down and/or readjust the trim angle.





EMD30012


DIGITAL TACHOMETER

This meter contains the tachometer, trim meter, oil level warning and overheat warning.

- ① Tachometer
- ② Trim meter
- ③ Oil level warning indicator
- ④ Overheat warning indicator

NOTE:

After the main switch is first turned on all portions of the meter come on as a check. The tachometer and trim meter will indicate the maximum reading and the oil-level warning indicator and overheat warning indicator will light. After a few seconds, the meters will change to normal operation. Watch the meter when turning on the main switch to make sure all segments come on.



EMD21010

Tachometer

This meter shows the engine speed.


EMD26110

Trim meter

This meter shows the trim angle of your outboard.

NOTE:

Memorize the trim angles that work best for your boat under different conditions. Adjust the trim angle to the desired setting by operating the power trim and tilt switch.



EMD21110


Oil-level warning indicator



If oil level falls below the lower limit, the warning indicator will start to blink. Refer to "OIL LEVEL WARNING" for the detail.

- ① Oil-level warning indicator

CAUTION:

Do not operate the engine without oil. Serious engine damage will occur.





EMD21210


Overheat warning indicator

If the engine temperature rises too high, the warning indicator will start to blink. Refer to "OVERHEAT WARNING" for the detail.

- ② Overheat warning indicator

CAUTION:

Do not continue to operate the engine if a warning device has activated. If necessary, refer to the "TROUBLESHOOTING" section in this manual. Consult your dealer if the problem cannot be located and corrected.



EMD40012



DIGITAL SPEEDOMETER

This meter contains the speedometer, fuel meter with warning, trip meter, clock and voltmeter with warning.

- ① Speedometer
- ② Fuel meter
- ③ Trip meter/clock/voltmeter
- ④ Warning indicator

NOTE:

After the main switch is first turned on, all portions of the meter come on as a check. After a few seconds, the meters will change to normal operation. Watch the meter when turning on the main switch to make sure all segments come on.




EMD25110

Speedometer

The meter will show the boat speed.

NOTE:


The speedometer displays km/h, mph, or knots, depending upon operator preference. Select the desired unit of measurement by setting the selector switch on the back of the meter. See the illustration for setting.



① Cap

② Selector switch (For speed unit)

③ Selector switch (For fuel sender)




EMD40110

Trip meter

Push and release the "mode" button until the indicator on the face of the meter points to "TRIP". The meter will display the distance the boat has traveled since the meter was last reset. To reset the trip meter to "0", press the "set" and "mode" button together.

NOTE:

- The trip distance will be shown in kilometers or miles depending upon the unit of measurement selected for the speedometer.
- The trip distance is kept in memory by battery power. The stored data will be lost if the battery is disconnected.



EMD40210


Clock

Push and release the "mode" button until the indicator on the face of the meter points to "TIME." The meter will indicate time.

To set the clock, be sure the meter is in the "TIME" mode. Press the "set" button; the hour display will begin blinking. Press the "mode" button until the desired hour is displayed. Press the "set" button again, the minute display will begin blinking. Press the "mode" button until the desired minute is displayed. Press the "set" button again to start the clock.

NOTE:

The clock operates on battery power. Disconnecting the battery will stop the clock. Reset the clock after connecting the battery.



EMD40310

Fuel meter



The fuel level is displayed by eight segments. When all segments are showing, the fuel is full.

CAUTION:

The Yamaha fuel tank sensor is different from a conventional-type sensor. A wrong setting of the selector switch on the meter will give incorrect readings. Consult Yamaha dealer for correct setting.

NOTE:

The fuel reading can be affected by the position of the sensor in the fuel tank and the attitude of the boat in the water. Operation with bow-up trim or continuous turning can give false readings.



EMD40410

Warning indicator

● Fuel warning



If the fuel level decreases to one segment the fuel level warning segment ① begins blinking.

● Low battery voltage warning

If battery voltage drops, the display ② will be automatically turned on and it begins blinking.

CAUTION:

Do not continue to operate the engine if a warning device has activated. Refer to the TROUBLESHOOTING section in this manual. Consult a Yamaha dealer if the problem cannot be located and corrected.




EMD42012

FUEL MANAGEMENT METER

Optional equipment




The meter contains the fuel flow meter, fuel consumption meter, fuel economy meter, twin engine speed synchronizer, water separator warning indicator.

- ① Fuel flow meter
- ② Fuel consumption/Fuel economy meter/Twin engine speed synchronizer
- ③ Water separator warning indicator (Operates only if the sensor has been installed.)



NOTE:

After the main switch is first turned on, all portions of the meter come on as a check. After a few seconds, the meters will change to normal operation. Watch the meter when turning on the main switch to make sure all segments come on.



EMD32010

Fuel flow meter

The meter displays fuel flow within one hour, at the rate of current engine operation.

If twin engines are installed on your boat, the meter will display total fuel flow of Port and Starboard side engine. It also displays PS indication at the same time.


By pressing "set" button, the meter will display fuel flow of starboard side engine and S indication.

By pressing "set" button again, the meter will display fuel flow of port side engine and P indication.

By pressing "set" button again, the meter will display total fuel flow.

NOTE:


- The meter displays gallon/hour and liter depending upon operator preference. Select the desired unit of measurement by setting the selector switch ① on the back of the meter during installation.
- Fuel consumption meter and Fuel economy meter will indicate same unit of measurement.




EMD32110

Fuel consumption meter

Push and release the "mode" button until the indicator on the face of the meter points to total ("TTL"). The meter will display the total amount of fuel consumed after the meter was last reset. To reset the total fuel consumption to "0", press the "set" and "mode" buttons together.



FUEL MANAGEMENT



EMD32210

Fuel economy

Push and release the "mode" button until the indicator on the face of the meter points to "ECON." The meter will display the distance per liter or gallon for the operator's reference when cruising.

NOTE:


If twin engines are installed on your boat, the meter will display only the total fuel economy of both engines.

NOTE:


- Fuel consumption will vary greatly with boat design, weight, propeller used, engine trim angle, sea conditions (including wind), and throttle position. Fuel consumption will also vary slightly with the type of water (salt, fresh, and contaminate levels), air temperature and humidity, cleanliness of the boat bottom, engine mounting height, skill of the operator, and individual gasoline formulation (winter or summer fuel and amount of additives).
- The Yamaha digital speedometer and fuel management meter calculates speed, miles traveled, and fuel economy by water movement at the stern of the boat. This distance can vary greatly from the actual distance traveled because of water currents, sea swells, and the condition of the water speed sensor (partially plugged or damaged).
- Individual engines may slightly vary in their fuel consumption due to manufacturing variations. These variations can be even greater if the engines are of different year models. In addition, variations in propellers, even of the same basic dimensions of the same design, can also cause a slight variation in fuel consumption.



FUEL MANAGEMENT




FUEL MANAGEMENT



- ① $\overline{nn}$ ---
- ② $\overline{n}$ ---
- ③ $\overline{5476}$
- ④ --- $\overline{n}$
- ⑤ --- $\overline{nn}$

FUEL MANAGEMENT



EMD32310

Twin engine speed synchronizer

Push and release the "mode" button until the indicator on the face of the meter points to "SYNC". The meter will display the difference of engine speed (r/min) between Port and Starboard engines for the reference when synchronizing the two engine's speeds.

- ① Port side engine speed is higher
- ② Port side engine speed is slightly higher
- ③ Engine speed is synchronized evenly between Port and Starboard side engines
- ④ Starboard side engine speed is slightly higher
- ⑤ Starboard side engine speed is higher

NOTE:

If the two engine's speeds are not synchronized while cruising, they can be synchronized by adjusting trim angle or throttle.



EMD32410

Water separator warning indication

NOTE:

This indicator operates only when an optional water separator sensor has been installed.


If the water which has been separated from fuel in the water trap exceeds a specific volume, the indicator will blink showing the need for water to be drained.



EMD60010

TILT SUPPORT LEVER


To keep the outboard motor in the tilted-up position, lock the tilt support lever to the clamp bracket.




EMD63210


TOP COWLING LOCK LEVERS**V6**

To remove the engine top cowling, pull up the front and rear lock levers. Then lift off the cowling. When replacing the cowling, check to be sure it fits properly in the rubber seal. Then lock the cowling again by moving the levers downward.






V4



V4



EMD64010

TOP COWLING RELEASE LEVER**V4**

The top cowling can be removed by operating the cowling release lever.

Pulling the front lever unlocks the top cowling for removal.

When refitting the top cowling:

- 1) Set the top cowling straight down onto the engine, being careful to avoid catching spark plug leads or other wires.
- 2) Align the three cowling hooks with the locks on the bottom cowling.
- 3) Press down on the top of the cowling at the front and both sides of the back until the three locks click.
- 4) To make sure the cowling is locked properly push the cowling from each side. If it lifts, repeat step 3.

CAUTION:

Make sure the cowling lock connection cable is operating correctly before reinstalling the top cowling.

- When the release lever is operated, both front and rear cowling hooks should be released at the same time. If not, adjust the cable adjuster for the rear clamps.
- Make sure the cable operates smoothly and is free of corrosion.
- Check that the cable is properly secured in the holder.
- When reinstalling the cowling, insure that both the front and rear locks have operated properly.

If the cowling has not been locked properly some parts may be damaged by the top cowling shaking during operation.




E

EMD80010

WARNING SYSTEM

CAUTION:

Do not continue to operate the engine if the warning device has activated. Consult your Yamaha dealer if the problem cannot be located and corrected.



EMD82312*

OVERHEAT WARNING

This engine has an overheat warning device.

If the engine temperature rises too high, the warning device will activate.

(○); Included (—); N/A

Warning device activation	Tiller control model	Remote control model
The engine speed will automatically decrease to about 2,000 r/min.		○
The overheat warning indicator will come on.		○*1
The buzzer will sound.		○



If the warning system has been activated, stop the engine and check the water inlet for clogging.

NOTE:


In case of dual engine drive;
Should the overheat warning system of one engine operate, it slows down and the buzzer sounds.

This will cause the other engine to slow down and the buzzer to sound.

For the other engine, the warning system can be released by shifting the remote control lever into the neutral.



*1. Digital tachometer



E

EMD84012*

OIL LEVEL WARNING / OIL FILTER CLOGGING WARNING

This engine has an oil level warning system.

If oil level falls below lower limit, the warning device will activate.

(○); Included (—); N/A

Warning device activation	Tiller control model	Remote control model
The engine speed will automatically decrease to about 2,000 r/min.	/	○
The oil level warning indicator will come on.	/	○
The buzzer will sound.	/	○





If the warning system has been activated, stop the engine and check for the cause.

NOTE:

The warning for oil filter clogging is similar to the warnings for low oil level and overheating.


For easy troubleshooting, it is advisable to check for engine overheating first, then oil level and finally oil filter clogging.

① Oil filter




905012

EMF00010



Chapter 3 OPERATION

INSTALLATION	3-1
Mounting the outboard motor	3-2
FILLING FUEL AND ENGINE OIL	3-4
Filling fuel	3-4
Filling oil	3-5
PRE-OPERATION CHECK	3-7
Operation after a long period of storage	3-8
BREAKING IN (RUNNING IN) ENGINE	3-9
 STARTING ENGINE	3-11
 WARMING UP ENGINE	3-16
 SHIFTING	3-17
Forward	3-17
Reverse	3-17
STOPPING ENGINE	3-18
 TRIMMING OUTBOARD MOTOR	3-19
Adjusting trim angle	3-20
DUAL ENGINE INSTALLATION/ SINGLE ENGINE RUNNING	3-22
 TILTING UP/DOWN	3-23
 CRUISING IN OTHER CONDITIONS	3-25
Cruising in salt water	3-25
Cruising in turbid water	3-25



EMF10010


INSTALLATION

CAUTION:

Incorrect engine height or obstructions to smooth water flow (such as the design or condition of the boat or accessories such as transom ladders/depth finder transducers) can create airborne water spray while the boat is cruising. Severe engine damage may result if the motor is operated continuously in the presence of airborne water spray.

NOTE:

During water testing check the buoyancy of the boat, at rest, with its maximum load. Check that the static water level on the exhaust housing is low enough to prevent water entry into the powerhead, when water rises due to waves when the outboard is not running.



EMF12210


MOUNTING THE OUTBOARD MOTOR

⚠WARNING

Improper mounting of the outboard motor could result in hazardous conditions such as poor handling, loss of control, or fire hazards. Observe the following:

- The information presented in this section is intended as reference only. It is not possible to provide complete instructions for every possible boat/motor combination. Proper mounting depends in part on experience and the specific boat/motor combination.
- Your dealer or other person experienced in proper rigging should mount the motor. If you are mounting the motor yourself, you should be trained by an experienced person. [permanent mounted type]
- Your dealer or other person experienced in proper outboard motor mounting should show you how to mount your motor. [portable type]

Mount the outboard motor on the center line (keel line) of the boat, and ensure that the boat itself is well balanced. Otherwise, the boat will be hard to steer. For boats without a keel or which are asymmetrical, consult your dealer.




- ① Center line (Keel line)

**⚠ WARNING**


Overpowering a boat may cause severe instability. Do not install an outboard motor with more horsepower than the maximum rating on the capacity plate of the boat. If the boat does not have a capacity plate, consult the boat manufacturer.

Mounting Height

To run your boat at optimum efficiency, the water-resistance (drag) of the boat and outboard motor must be made as little as possible. The mounting-height of the outboard motor greatly affects the water-resistance. If the mounting-height is too high, cavitation tends to occur, thus reducing the propulsion; and if the propeller tips cut the air, the engine speed will rise abnormally and cause the engine to overheat. If the mounting-height is too low, the water-resistance will increase and thereby reduce engine efficiency. Mount the engine so that the anticavitation plate is in alignment with the bottom of the boat.

**NOTE:**

The optimum mounting height of the outboard motor is affected by the boat/motor combination. Test runs at different heights can help determine the optimum mounting height.



FILLING FUEL AND ENGINE OIL

FILLING FUEL

- 1) Remove the fuel tank cap.
- 2) Fill the fuel tank carefully.
- 3) Close the cap securely after refueling.
Wipe up any spilled fuel.


Fuel tank capacity:
Refer to "SPECIFICATIONS", Page 4-1.

Ring Free Fuel Additive

Gasoline is a precise blend of many different substances, each chosen to give certain characteristics. Gasoline blends have been changing in recent years in response to concerns about pollution and resulting emissions regulations. One of the most obvious changes has been the elimination of lead from most fuels.

As gasoline has changed, the amount of additives such as aromatics and oxygenates has increased. These additives are important for the engines in passenger cars, but they can have detrimental effects in marine engines, particularly 2 cycle outboards because of increased deposits in the combustion chamber. When enough deposits collect, piston rings begin sticking. Performance drops and engine wear increases dramatically.


While many additives available may reduce deposits, Yamaha recommends the use of **Ring Free Fuel Additive**, available from your Yamaha dealer. Ring Free has repeatedly proven its ability to clean combustion deposits from inside the engine, notably the critical piston-ring-land area, and fuel system components. Follow product labeling for use instructions



EMF32210

FILLING OIL (for Precision blend system model)

This engine uses the YAMAHA PRECISION BLEND SYSTEM, which provides superior lubrication by ensuring the proper oil ratio for all operating conditions. No fuel premixing is needed (except during break-in/running-in). Simply pour gasoline into the fuel tank and oil into the oil tank.



Convenient indicator segments indicate condition of the oil supply. Refer to oil warning system.



To fill the engine oil into the oil tanks, proceed as follows:

⚠ WARNING

Do not add gasoline (Petrol) to the oil tank. Fire or explosion could result.

Engine oil tank capacity:

Refer to "SPECIFICATION", page 4-1.




When remote oil tank is used:

Pour oil into the remote oil tank and turn the main switch to "ON", and the YAMAHA PRECISION BLEND SYSTEM automatically feeds the oil from the remote oil tank to the engine oil tank in the top cowling.

After refilling, turn the main switch to "OFF". Then, proceed to start the engine. Otherwise, the oil-level warning system may prevent the engine from revving up.

CAUTION:

When the engine is operated for the first time or stored for a period of time, a minimum of 5 liters (5.3 US qt, 4.4 Imp qt) of oil should be kept in the remote oil tank. Otherwise, the oil-feed pump chamber will not be filled with oil, and no oil will be supplied.




EMD33410*

Oil level indicator

The various oil level system functions are as follows:

Oil level warning indicator (Digital tachometer)	Oil level warning indicator lamp (Analog tachometer)	Engine oil tank	Remote oil tank	Remarks
	Green 	More than 300 cm ³ (0.32 US qt, 0.26 Imp qt) 	More than 1,500 cm ³ (1.6 US qt, 1.31 Imp qt) 	No refilling necessary.
	Yellow 	More than 300 cm ³ (0.32 US qt, 0.26 Imp qt) 	1,500 cm ³ (1.6 US qt, 1.31 Imp qt) or less 	Add oil, refer to oil filling.
	Red Green 	300 cm ³ (0.32 US qt, 0.26 Imp qt) or less 	More than 1,500 cm ³ (1.6 US qt, 1.31 Imp qt) 	Check oil filter for clogging. Check battery cable connection.
	Red 	300 cm ³ (0.32 US qt, 0.26 Imp qt) or less 	1,500 cm ³ (1.6 US qt, 1.31 Imp qt) or less 	Oil has not been added. Buzzer sounds in the remote control box and engine speed is automatically reduced to about 2,000 r/min to help conserve oil. Refer to Chapter 5.



EMF40110

PRE-OPERATION CHECK

⚠ WARNING

If any item in the pre-operation check is not working properly, have it inspected and repaired before operating the outboard motor. Otherwise, an accident could occur.

Fuel

Check to be sure you have plenty of fuel for your trip. Make sure there are no fuel leaks or gasoline fumes.

Be sure the fuel hose is not being flattened or kinked by objects in the boat, and that there are no sharp objects near it.

Oil

Check to be sure you have plenty of oil for your trip.

Controls

Check throttle, shift, and steering for proper operation before starting the engine.

The controls should work smoothly, without binding or unusual free play. Look for loose or damaged connections.


Check operation of the starter and stop switches when the outboard motor is in the water.

Engine

Check the engine and engine mounting. Look for loose or damaged fasteners. Check the propeller for damage.

CAUTION:

Do not start the engine out of water. Overheating and serious engine damage can occur.





EMF44010

OPERATION AFTER A LONG PERIOD OF STORAGE

(for precision blend system)

When operating the engine after a long period (12 months) of storage, proceed as follows:

- 1) Use a 50 : 1 gasoline-oil mixture to start the engine.
- 2) Start the engine.
Leave it idling.




⚠ WARNING

- Do not touch or remove electrical parts when starting or during operation.
- Keep hands, hair, and clothes away from flywheel and other rotating parts while engine is running.

- 3) Watch for oil flowing through the oil feed pipes. After any air in the oil lines has been expelled, YAMAHA PRECISION BLEND SYSTEM should supply oil normally. If no oil has begun flowing after 10 minutes of idling, consult your Yamaha dealer.

CAUTION

When operating the engine after a long period of storage, be sure to take the above steps; otherwise, engine seizure may occur.



EMF50110

BREAKING IN (RUNNING IN) ENGINE

Your new engine requires a period of break-in (running-in) to allow mating surfaces of moving parts to wear-in evenly. Correct break-in (running-in) will help ensure proper performance and longer engine life.

CAUTION:

- Failure to follow the break-in (running-in) procedure may result in reduced engine life or even severe engine damage.
- Premix fuel must be used during break-in (running-in) in addition to oil in the YAMAHA PRECISION BLEND SYSTEM.

Break-in (running-in) time: 10 hours

Break-in (running-in) premix ratio
Gasoline (petrol) : Oil=50 : 1


Mixing ratio	50 : 1			
	1 L (0.26 US gal, 0.22 Imp gal)	12 L (3.2 US gal, 2.6 Imp gal)	14 L (3.7 US gal, 3.1 Imp gal)	24 L (6.3 US gal, 5.3 Imp gal)
Gasoline (Petrol)				
Engine oil	0.02 L (0.02 US qt, 0.02 Imp qt)	0.24 L (0.25 US qt, 0.21 Imp qt)	0.28 L (0.30 US qt, 0.25 Imp qt)	0.48 L (0.51 US qt, 0.42 Imp qt)

CAUTION:

Make sure to mix gasoline (petrol) and oil completely, otherwise your outboard motor may be damaged.

**Procedure**

- 1) First 10 minutes: Run the engine at the lowest possible-speed. A fast idle in neutral is best.
- 2) Next 50 minutes: Do not exceed half throttle (approximately 3,000 rpm). Vary engine speed occasionally. If you have an easy-planing boat, accelerate at full throttle onto plane, then immediately reduce the throttle to 3,000 rpm or less.
- 3) Second hour: Accelerate at full throttle onto plane, then reduce engine speed to three-quarter throttle (approximately 4,000 rpm). Vary engine speed occasionally. Run at full throttle for one minute, then allow about 10 minutes of operation at three-quarter throttle or less to let the engine cool.
- 4) Third through tenth hours: Avoid operating at full throttle for more than 5 minutes at a time. Let the engine cool between full-throttle runs. Vary engine speed occasionally.
- 5) After the first 10 hours, operate the engine normally. Use straight gasoline (petrol) in the fuel tank; YAMAHA PRECISION BLEND SYSTEM provides proper lubrication for normal operation.



EMF58010

STARTING ENGINE

⚠ WARNING

Before starting the engine, make sure that the boat is tightly moored and that you can be steered clear of any obstructions. Be sure there are no swimmers in the water near you.

⚠ WARNING

When inserting the fuel joint into the fuel tank, gasoline (petrol) vapor will be released. Gasoline (petrol) is highly flammable, and its vapors are flammable and explosive. Refrain from smoking, and keep away from open flames and sparks while inserting the fuel-joint.


EMF77411

PROCEDURE FOR REMOTE CONTROL MODEL


- 1) Firmly connect the fuel joint to the fuel tank. If the fuel joint is provided on the motor, firmly connect the fuel joint to the motor.
- 2) If the air vent screw is provided on the fuel tank cap loosen it by 2 or 3 turns.

NOTE:

During engine operation place the fuel tank horizontally, or fuel could not be sucked.





- 3) Squeeze the primer bulb with the outlet end up until you feel it become firm.

**E**



- 4) Place the remote control lever in the Neutral position.

NOTE:

The start-in-gear protection device permits the engine to be started only when it is in Neutral.

**Side mount type**

- 5) Lift the neutral throttle lever on the remote control box upwards partially. You may need to change the throttle opening slightly depending on engine temperature. As a starting point, lift the lever just until you feel resistance, then lift slightly more.




Binnacle mount type

- 5) While pushing the free accelerator button, rotate the remote control lever (free accelerator lever) 35° forward.

NOTE:

The rotation angle of the remote control lever (free accelerator lever) should be determined upon the engine temperature. (When the engine is cold, it is necessary to rotate the lever a little farther.)


- ① Fully-closed
- ② Fully-open
- ③ Free accelerator




- 6) Attach the engine stop switch lanyard to a secure place on your clothing, or your arm or leg. Then, install the lock plate on the other end of the lanyard in the engine stop switch.


⚠ WARNING

- Attach the engine stop switch lanyard to a secure place on your clothing, your arm or leg while operating.
- Do not attach the lanyard to clothing that could tear loose. Do not route the lanyard where it could become entangled, preventing it from functioning.
- Avoid accidentally pulling the lanyard during normal operation. Loss of engine power means the loss of most steering control. Also, without engine power, the boat could slow rapidly. This could cause people and objects in the boat to be thrown forward.






E



7) Turn the main switch to "ON".

NOTE:


In case of dual-engine operation, when the main switch is turned on, the buzzer operates for a few seconds and stops automatically. Should either of the dual engines stall, the buzzer operates.



8) Press in and hold the main switch to operate the remote choke system.
(The remote choke switch returns to its home position when you release your hand. Therefore, keep the switch pressed in.)




NOTE:

- It is not necessary to use the choke when the engine is warm.
- Set the the choke knob to the home position, or the remote choke system will not operate.



- 9) Turn the main switch to "START", and hold it for a maximum of 5 seconds.
- 10) Immediately after the engine starts, release the main switch to return it to "ON".

701041



- 11) Return the free accelerator lever gradually to its home position so that the engine does not stall.


CAUTION:

- Do not turn the main switch to "START" when the engine is running.
- Do not keep the starter motor turning for more than 5 seconds with the main switch in the "START" position. If the engine does not start within 5 seconds, return the main switch to "ON", wait 10 seconds, and then crank the engine again. (If you continuously run the starter motor for more than 5 seconds, the starter can be damaged. The battery will also run down quickly, making it harder to start the engine.)



EMG00010


WARMING UP ENGINE



- 1) Before beginning operation, allow the engine to warm up at idling speed for 3 minutes. (Failure to do this will shorten engine life.)
- 2) Check for a steady flow of water from the cooling-water pilot hole.

CAUTION

A continuous flow of water from the pilot hole shows that the water pump is pumping water through the cooling passages. If water is not flowing out of the pilot hole at all times while the engine is running, do not continue to run the engine. Overheating and serious damage could occur. Stop the engine and check to see if the water inlet on the lower casing is blocked. If the problem cannot be found and corrected, consult your Yamaha dealer.



EMG20310*


SHIFTING

⚠ WARNING

Before shifting, make sure there are no swimmers or obstacles in the water near you.

CAUTION

To change the shifting position from forward to reverse or vice-versa, close the throttle first so that the engine idles (or runs at low speeds).




FORWARD

Pull up the neutral interlock trigger (If equipped) and move the remote control lever quickly and firmly from Neutral to Forward.



REVERSE

Pull up the neutral interlock trigger (If equipped) and move the remote control lever quickly and firmly from Neutral to Reverse.



⚠ WARNING

When operating in Reverse, go slowly. Do not open the throttle more than half. Otherwise, the boat may become unstable, which could result in loss of control and an accident.




EMG38010

STOPPING ENGINE

Let it cool off for a few minutes at idle or low speed first. Stopping the engine immediately after operating at high speed is not recommended.

EMG41511


- 1) Turn the main switch to "OFF".



NOTE:


The engine can also be stopped by pulling the lanyard from the engine stop switch (then turning the main switch to "OFF").

- 2) Tighten the air vent screw on the fuel tank cap after stopping the engine, if it is equipped.
- 3) Remove the key if the boat will be left unattended.



EMG60410

TRIMMING OUTBOARD MOTOR





The trim angle of the outboard motor helps determine the position of the bow of the boat in the water. The correct trim angle will help improve performance and fuel economy while reducing strain on the engine. The correct trim angle depends upon the combination of boat, engine, and propeller. Correct trim is also affected by variables such as the load in the boat, sea conditions, and running speed.

⚠ WARNING

Excessive trim for the operating conditions (either trim up or trim down) can cause boat instability and can make steering the boat more difficult. This increases the possibility of an accident. If the boat begins to feel unstable or is hard to steer, slow down and/or readjust the trim angle.


① Trim operating angle



ADJUSTING TRIM ANGLE (for Power trim and tilt model)


To adjust the trim angle, operate the power trim and tilt switch. To raise the bow ("trim-out"), push the switch UP. To lower the bow ("trim-in"), push the switch DOWN. Make test runs with the trim set to different angles to find the position that works best for your boat and operating conditions.

- ① Power trim and tilt switch




⚠ WARNING

Use caution when trying a trim position for the first time. Increase speed gradually and watch for any signs of instability or control problems. Improper trim angle can cause loss of control.




Bow up

When the boat is on plane, a bow-up attitude result in less drag, greater stability and efficiency. This is generally when the keel line of the boat is up about 3 to 5 degrees. When trimmed out, the boat may have more tendency to steer to one side or the other. Compensate for this as you steer. The trim tab can also be adjusted to help offset this effect.



Too much trim-out puts the bow of the boat too high in the water. Performance and economy are decreased because the hull of the boat is pushing the water and there is more air drag.

Excessive trim-up can cause the propeller to ventilate, which reduces performance further. When trimmed-out too much, a boat may “porpoise” (hop in the water), which could throw the operator and passengers overboard.




Bow down


When the bow of the boat is down, it is easier to accelerate from a standing start onto plane.

Too much trim-in causes the boat to “plow” through the water, decreasing fuel economy and making in hard to increase speed.


Operating with excessive trim-in at higher speeds also makes the boat unstable. Resistance at the bow is greatly increased, heightening the danger of “bow steering” and making operation difficult and dangerous.



- ① Bow up
- ② Bow down
- ③ Optimum angle



EMH40011



DUAL ENGINE INSTALLATION/SINGLE ENGINE RUNNING


Using only one of the engines in case of emergency, be sure to keep the unused one tilted up and operate the other engine at low speed.

CAUTION:


If the boat is operated with one engine in the water but not running, water may run into the exhaust pipe due to wave action, causing engine trouble.

NOTE:

When you are maneuvering at low speed, such as near a dock, it is recommended that both engines be running with one in neutral gear. Then, if the engine you are using stops, you can immediately switch to the other engine.



EMH10110



TILTING UP/DOWN

If the engine will be stopped for some time, or if the boat is moored in shallows, the engine should be tilted up to protect the propeller and casing from damage by collision with obstructions, and also to reduce salt corrosion.

CAUTION:

- Before tilting the motor, follow the procedures under "STOPPING ENGINE". Never tilt the motor while the engine is running. Severe damage from overheating can result.
- Do not tilt up the engine by pushing the steering handle as this could break the handle.
- Keep the power unit higher than the propeller at all times. Otherwise, water can run into the cylinder, causing damage.

⚠ WARNING


Be sure all people are clear of the outboard motor when adjusting the tilt angle, also be careful not to pinch any body parts between the drive unit and engine bracket.

⚠ WARNING


Leaking fuel is a fire hazard. Disconnect the fuel line if the engine will be tilted for more than a few minutes. Otherwise, fuel may leak. (If the fuel connector is provided on the motor.)



EMH23111

PROCEDURE FOR TILTING UP**Power trim and tilt**


- 1) Push the power trim and tilt switch "UP" until the outboard has tilted up completely.




- 2) Turn the tilt-support lever toward you and support the engine.

⚠ WARNING


After tilting the engine, be sure to support it with the tilt-support lever. Otherwise, the engine could fall back down suddenly if oil in the power trim and tilt unit should lose pressure.



- 3) Remove the fuel-line connection from the motor. (If the fuel connector is provided on the motor.)



411014



411021

- 4) Once the engine is supported with the tilt-support lever, push the power trim and tilt switch "DN" (Down) to retract the trim rods.

CAUTION:

Be sure to retract the trim rods completely during mooring. This protects the rods from marine growths and corrosion which could damage the power trim and tilt mechanism.

PROCEDURE FOR TILTING DOWN**Power trim and tilt**

- 1) Push the power trim and tilt switch "UP" until the engine is supported by the tilt rod.
- 2) Release the tilt-support lever.
- 3) Push the power trim and tilt switch "DN" (Down) to lower the engine to the desired position.

EMH60010

CRUISING IN OTHER CONDITIONS

CRUISING IN SALT WATER

After operating in salt water, wash out the cooling-water passages with fresh water to prevent them from becoming clogged-up with salt deposits.



NOTE:

Refer to cooling system flushing instructions in **STORING AND TRANSPORTING OUTBOARD MOTOR**.

CRUISING IN TURBID WATER

It is strongly recommended that the optional chromium-plated water-pump kit be installed if the outboard is to be used in turbid (muddy) water conditions.

EMK00010



Chapter 4

MAINTENANCE

SPECIFICATION DATA.....4-1

TRANSPORTING AND STORING

OUTBOARD MOTOR4-9

Trailing outboard motor.....4-9

Storing outboard motor4-10

PERIODIC MAINTENANCE.....4-12

Replacement parts4-12

Maintenance chart.....4-13

Cleaning and adjusting spark plug...4-14

Checking fuel system.....4-16

Cleaning fuel filter4-17

Adjusting idling speed.....4-18

Checking water trap under engine
oil tank4-19

Replacing fuse4-20

Checking wiring and connectors4-20

Exhaust leakage.....4-20

Water leakage4-20

Greasing4-21

Checking power trim and tilt
system4-23

Checking propeller4-24

Changing gear oil4-26

Inspecting and replacing anode4-27

Checking battery.....4-28

Checking bolts and nuts4-32

Motor exterior.....4-32

Coating the boat bottom4-33



E

EMK10010

SPECIFICATION DATA

Item	Model	Unit	115TRW/S115TRW
DIMENSIONS			
• Overall Length		mm (in.)	808 (31.8)
• Overall Height L/X		mm (in.)	1,472 (58.0)/1,599 (63.0)
• Overall Width		mm (in.)	582 (22.9)
• Transom height L/X		mm (in.)	516 (20.3)/642 (25.3)
• Weight L/X		kg (lb.)	167 (368)/171 (377)
PERFORMANCE			
• Full throttle operating range		r/min	4,500 ~ 5,500
• Maximum output		kW (HP)	84.6 (115) at 5,000 r/min
• Idling speed (in neutral)		r/min	700~800
ENGINE			
• Engine type			2-stroke, 90°V
Number of cylinder			4
Displacement		cm ³ (cu.in.)	1,730 (105.6)
Bore × stroke		mm (in.)	90.0 × 68.0 (3.54 × 2.68)
• Ignition system			C.D.I system
• Spark plug		NGK	BR8HS-10
Spark plug gap		mm (in.)	0.9~1.0 (0.035~0.039)
• Control system			Remote control
• Starting system			Electric start
• Battery capacity		V-AH (kc)	12-70 (252) ~ 100 (360)
Minimum cold crank performance		Amps at -17.8°C (0°F)	380
Minimum reserve capacity		minutes at 26.7°C (80°F)	124
• Alternator output		V-A (W)	12-20
• Starting carburation system			Choke valve start system
DRIVE UNIT			
• Gear positions			Forward-Neutral-Reverse
Gear ratio			2.00 (26/13)
• Trim/tilt system			Power trim/tilt
• Propeller mark			K
FUEL AND OIL			
• Fuel			Regular unleaded gasoline (P.O.N.: minimum 86)
Fuel tank capacity		L (US gal, Imp gal)	—
• Recommended engine oil			YAMALUBE 2 STROKE OUTBOARD OIL or an equivalent TC-W3 certified outboard oil
Oil tank capacity		L (US qt, Imp qt)	Remote: 10.5 (11.1, 9.2) Engine: 0.9 (0.95, 0.79)
Fuel/oil ratio			YAMAHA PRECISION BLEND SYSTEM
• Recommended gearcase oil			Hypoid gear oil (SAE90)
Gear oil capacity		cm ³ (US oz, Imp oz)	760 (25.7, 26.8)
TIGHTNING TORQUE			
• Spark plug		Nm (m•kg, ft•lb)	25 (2.5, 18)
• Propeller nut		Nm (m•kg, ft•lb)	55 (5.5, 40)



130TRW/S130TRW	L130TRW	150TRW/S150TRW
808 (31.8) 1,472 (58.0)/1,159 (63.0) 582 (22.9) 516 (20.3)/642 (25.3) 167 (368)/171 (377)	808 (31.8) —/1,599 (63.0) 582 (22.9) —/642 (25.3) —/171 (377)	823 (32.4) 1,615 (63.6)/1,742 (68.6) 577 (22.7) 516 (20.3)/642 (25.3) 194 (428)/198 (437)
5,000~6,000 95.6 (130) at 5,500 r/min 700~800	5,000~6,000 95.6 (130) at 5,500 r/min 700~800	4,500 ~ 5,500 110.3 (150) at 5,000 r/min 675~725
2-stroke, 90°V 4 1,730 (105.6) 90.0 × 68.0 (3.54 × 2.68) C.D.I system BR9HS-10 0.9~1.0 (0.035~0.039) Remote control Electric start 12-70 (252) ~ 100 (360) 380 124 12-20 Choke valve start system	2-stroke, 90°V 4 1,730 (105.6) 90.0 × 68.0 (3.54 × 2.68) C.D.I system BR9HS-10 0.9~1.0 (0.035~0.039) Remote control Electric start 12-70 (252) ~ 100 (360) 380 124 12-20 Choke valve start system	2-stroke, 90°V 6 2,596 (158.4) 90.0 × 68.0 (3.54 × 2.68) C.D.I system (Microcomputer) BR7HS-10 0.9~1.0 (0.035~0.039) Remote control Electric start 12-70 (252) ~ 100 (360) 380 124 12-25 Choke valve start system
Forward-Neutral-Reverse 2.00 (26/13) Power trim/tilt K	Forward-Neutral-Reverse 2.00 (26/13) Power trim/tilt KL	Forward-Neutral-Reverse 1.86 (26/14) Power trim/tilt M
Regular unleaded gasoline (P.O.N.: minimum 86) — YAMALUBE 2 STROKE OUTBOARD OIL or an equivalent TC-W3 certified outboard oil Remote: 10.5 (11.1, 9.2) Engine: 0.9 (0.95, 0.79) YAMAHA PRECISION BLEND SYSTEM Hypoid gear oil (SAE90) 760 (25.7, 26.8)	Regular unleaded gasoline (P.O.N.: minimum 86) — YAMALUBE 2 STROKE OUTBOARD OIL or an equivalent TC-W3 certified outboard oil Remote: 10.5 (11.1, 9.2) Engine: 0.9 (0.95, 0.79) YAMAHA PRECISION BLEND SYSTEM Hypoid gear oil (SAE90) 715 (24.2, 25.2)	Regular unleaded gasoline (P.O.N.: minimum 86) — YAMALUBE 2 STROKE OUTBOARD OIL or an equivalent TC-W3 certified outboard oil Remote: 10.5 (11.1, 9.2) Engine: 0.9 (0.95, 0.79) YAMAHA PRECISION BLEND SYSTEM Hypoid gear oil (SAE90) 980 (33.1, 34.5)
25 (2.5, 18) 55 (5.5, 40)	25 (2.5, 18) 55 (5.5, 40)	25 (2.5, 18) 55 (5.5, 40)



EMK10010

SPECIFICATION DATA

Model	Unit	L150TRW
term		
DIMENSIONS		
• Overall Length	mm (in.)	823 (32.4)
• Overall Height L/X	mm (in.)	1,615 (63.6)/1,742 (68.6)
• Overall Width	mm (in.)	577 (22.7)
• Transom height L/X	mm (in.)	516 (20.3)/642 (25.3)
• Weight L/X	kg (lb.)	196 (432)/200 (441)
PERFORMANCE		
• Full throttle operating range	r/min	4,500 ~ 5,500
• Maximum output	kW (HP)	110.3 (150) at 5,000 r/min
• Idling speed (in neutral)	r/min	675~725
ENGINE		
• Engine type		2-stroke, 90°V
Number of cylinder		6
Displacement	cm ³ (cu.in.)	2,596 (158.4)
Bore x stroke	mm (in.)	90.0 x 68.0 (3.54 x 2.68)
• Ignition system		C.D.I system (Microcomputer)
• Spark plug	NGK	BR7HS-10
Spark plug gap	mm (in.)	0.9~1.0 (0.035~0.039)
• Control system		Remote control
• Starting system		Electric start
• Battery capacity	V-AH (kc)	12-70 (252) ~ 100 (360)
Minimum cold crank performance	Amps at -17.8°C (0°F)	380
Minimum reserve capacity	minutes at 26.7°C (80°F)	124
• Alternator output	V-A (W)	12-25
• Starting carburation system		Choke valve start system
DRIVE UNIT		
• Gear positions		Forward-Neutral-Reverse
Gear ratio		1.86 (26/14)
• Trim/tilt system		Power trim/tilt
• Propeller mark		ML
FUEL AND OIL		
• Fuel		Regular unleaded gasoline (P.O.N.: minimum 86)
Fuel tank capacity	L (US gal, Imp gal)	-
• Recommended engine oil		YAMALUBE 2 STROKE OUTBOARD OIL or an equivalent TC-W3 certified outboard oil
Oil tank capacity	L (US qt, Imp qt)	Remote: 10.5 (11, 1, 9, 2)
Fuel/oil ratio		Engine: 0.9 (0.95, 0, 79)
• Recommended gearcase oil		YAMAHA PRECISION BLEND SYSTEM
Gear oil capacity	cm ³ (US oz, Imp oz)	Hypoid gear oil (SAE90) 870 (29.4, 30.6)
TIGHTNING TORQUE		
• Spark plug	Nm (m•kg, ft•lb)	25 (2.5, 18)
• Propeller nut	Nm (m•kg, ft•lb)	55 (5.5, 40)



P150TRW	S175TRW	P175TRW
823 (32.4) 1,615 (63.6)/— 577 (22.7) 516 (20.3)/— 194 (428)/—	823 (32.4) —/1,742 (68.6) 577 (22.7) —/642 (25.3) —/198 (437)	823 (32.4) 1,615 (63.6)/— 577 (22.7) 516 (20.3)/— 194 (428)/—
4,500 ~ 5,500 110.3 (150) at 5,000 r/min 675~725	4,500 ~ 5,500 128.7 (175) at 5,000 r/min 675~725	4,500 ~ 5,500 128.7 (175) at 5,000 r/min 675~725
2-stroke, 90°V 6 2,596 (158.4) 90.0 × 68.0 (3.54 × 2.68) C.D.I system (Microcomputer) BR7HS-10 0.9~1.0 (0.035~0.039) Remote control Electric start 12-70 (252) ~ 100 (360) 380 124 12-25 Choke valve start system	2-stroke, 90°V 6 2,596 (158.4) 90.0 × 68.0 (3.54 × 2.68) C.D.I system (Microcomputer) BR8HS-10 0.9~1.0 (0.035~0.039) Remote control Electric start 12-70 (252) ~ 100 (360) 380 124 12-25 Choke valve start system	2-stroke, 90°V 6 2,596 (158.4) 90.0 × 68.0 (3.54 × 2.68) C.D.I system (Microcomputer) BR8HS-10 0.9~1.0 (0.035~0.039) Remote control Electric start 12-70 (252) ~ 100 (360) 380 124 12-25 Choke valve start system
Forward-Neutral-Reverse 2.0 (28/14) Power trim/tilt M	Forward-Neutral-Reverse 1.86 (26/14) Power trim/tilt M	Forward-Neutral-Reverse 1.86 (26/14) Power trim/tilt M
Regular unleaded gasoline (P.O.N.: minimum 86) — YAMALUBE 2 STROKE OUTBOARD OIL or an equivalent TC-W3 certified outboard oil Remote: 10.5 (11, 1, 9, 2) Engine: 0.9 (0.95, 0, 79) YAMAHA PRECISION BLEND SYSTEM Hypoid gear oil (SAE90) 980 (33.1, 34.5)	Regular unleaded gasoline (P.O.N.: minimum 86) — YAMALUBE 2 STROKE OUTBOARD OIL or an equivalent TC-W3 certified outboard oil Remote: 10.5 (11, 1, 9, 2) Engine: 0.9 (0.95, 0, 79) YAMAHA PRECISION BLEND SYSTEM Hypoid gear oil (SAE90) 980 (33.1, 34.5)	Regular unleaded gasoline (P.O.N.: minimum 86) — YAMALUBE 2 STROKE OUTBOARD OIL or an equivalent TC-W3 certified outboard oil Remote: 10.5 (11, 1, 9, 2) Engine: 0.9 (0.95, 0, 79) YAMAHA PRECISION BLEND SYSTEM Hypoid gear oil (SAE90) 980 (33.1, 34.5)
25 (2.5, 18) 55 (5.5, 40)	25 (2.5, 18) 55 (5.5, 40)	25 (2.5, 18) 55 (5.5, 40)



EMK10010

SPECIFICATION DATA

Item	Model	Unit	200TRW/S200TRW
DIMENSIONS			
• Overall Length		mm (in.)	823 (32.4)
• Overall Height L/X/U		mm (in.)	1,615 (63.6)/1,742 (68.6)
• Overall Width		mm (in.)	577 (22.7)
• Transom height L/X/U		mm (in.)	516 (20.3)/642 (25.3)
• Weight L/X/U		kg (lb.)	194 (428)/198 (437)
PERFORMANCE			
• Full throttle operating range		r/min	4,500 ~ 5,500
• Maximum output		kW (HP)	147.1 (200) at 5,000 r/min
• Idling speed (in neutral)		r/min	675~725
ENGINE			
• Engine type			2-stroke, 90°V
Number of cylinder			6
Displacement	cm ³ (cu.in.)		2,596 (158.4)
Bore × stroke	mm (in.)		90.0 × 68.0 (3.54 × 2.68)
• Ignition system			C.D.I system (Microcomputer)
• Spark plug	NGK		BR8HS-10
Spark plug gap	mm (in.)		0.9~1.0 (0.035~0.039)
• Control system			Remote control
• Starting system			Electric start
• Battery capacity	V-AH (kc)		12-70 (252) ~ 100 (360)
Minimum cold crank performance	Amps at -17.8°C (0°F)		380
Minimum reserve capacity	minutes at 26.7°C (80°F)		124
• Alternator output	V-A (W)		12-25
• Starting carburation system			Choke valve start system
DRIVE UNIT			
• Gear positions			Forward-Neutral-Reverse
Gear ratio			1.86 (26/14)
• Trim/tilt system			Power trim/tilt
• Propeller mark			M
FUEL AND OIL			
• Fuel			Regular unleaded gasoline (P.O.N.: minimum 86)
Fuel tank capacity	L (US gal, Imp gal)		—
• Recommended engine oil			YAMALUBE 2 STROKE OUTBOARD OIL or an equivalent TC-W3 certified outboard oil
Oil tank capacity	L (US qt, Imp qt)		Remote: 10.5 (11, 1, 9, 2) Engine: 0.9 (0.95, 0, 79)
Fuel/oil ratio			YAMAHA PRECISION BLEND SYSTEM
• Recommended gearcase oil			Hypoid gear oil (SAE90)
Gear oil capacity	cm ³ (US oz, Imp oz)		980 (33.1, 34.5)
TIGHTNING TORQUE			
• Spark plug	Nm (m•kg, ft•lb)		25 (2.5, 18)
• Propeller nut	Nm (m•kg, ft•lb)		55 (5.5, 40)



L200TRW	P200TRW	—
823 (32.4) 1,615 (63.6)/1,742 (68.6) 577 (22.7) 516 (20.3)/642 (25.3) 196 (432)/200 (441)	823 (32.4) 1,615 (63.6)/— 577 (22.7) 516 (20.3)/— 194 (428)/—	
4,500 ~ 5,500 147.1 (200) at 5,000 r/min 675~725	5,000 ~ 6,000 147.1 (200) at 5,500 r/min 675~725	
2-stroke, 90°V 6 2,596 (158.4) 90.0 × 68.0 (3.54 × 2.68) C.D.I system (Microcomputer) BR8HS-10 0.9~1.0 (0.035~0.039) Remote control Electric start 12-70 (252) ~ 100 (360) 380 124 12-25 Choke valve start system	2-stroke, 90°V 6 2,596 (158.4) 90.0 × 68.0 (3.54 × 2.68) C.D.I system (Microcomputer) BR8HS-10 0.9~1.0 (0.035~0.039) Remote control Electric start 12-70 (252) ~ 100 (360) 380 124 12-25 Choke valve start system	
Forward-Neutral-Reverse 1.86 (26/14) Power trim/tilt ML	Forward-Neutral-Reverse 1.86 (26/14) Power trim/tilt M	
Regular unleaded gasoline (P.O.N.: minimum 86) — YAMALUBE 2 STROKE OUTBOARD OIL or an equivalent TC-W3 certified outboard oil Remote: 10.5 (11, 1, 9, 2) Engine: 0.9 (0.95, 0, 79) YAMAHA PRECISION BLEND SYSTEM Hypoid gear oil (SAE90) 870 (29.4, 30.6)	Regular unleaded gasoline (P.O.N.: minimum 86) — YAMALUBE 2 STROKE OUTBOARD OIL or an equivalent TC-W3 certified outboard oil Remote: 10.5 (11, 1, 9, 2) Engine: 0.9 (0.95, 0, 79) YAMAHA PRECISION BLEND SYSTEM Hypoid gear oil (SAE90) 980 (33.1, 34.5)	
25 (2.5, 18) 55 (5.5, 40)	25 (2.5, 18) 55 (5.5, 40)	




EMK20010

TRANSPORTING AND STORING OUTBOARD MOTOR

TRAILERING OUTBOARD MOTOR

The motor should be trailered and stored in the normal running position. If there is insufficient road clearance in this position, then trailer the motor in the tilt position using a motor support device such as a transom saver bar.



CAUTION

Do not use the tilt support lever/knob when trailering the boat. The outboard motor could shake loose from the tilt support and fall. If the motor can not be trailered in the down position, use an additional support device to secure it in the up position.

⚠ WARNING

- Never get under the lower unit while it is tilted, even if a motor support bar is used. Severe injury could occur if the outboard accidentally falls.
- **USE CARE** when transporting fuel tank, whether in a boat or car.
DO NOT fill fuel container to maximum capacity.
Gasoline will expand considerably as it warms up and can build up pressure in the fuel container. This can cause fuel leakage and a potential fire hazard.



EMK22110*

STORING OUTBOARD MOTOR

When storing your Yamaha outboard for prolonged periods of time, (2 months or longer), several important procedures must be performed to prevent expensive damage. This is especially important for your Precision Blend equipped outboard due to the lean oil ratios used at idle prior to shutting the engine off for the season.


It is advisable to have your outboard serviced by an authorized Yamaha dealer prior to storage. However, the following procedures can be performed by you, the owner, with a minimum of tools.

Filling Fuel Tank

Fill the fuel tank with fresh fuel and add one ounce of "Yamaha fuel conditioner and stabilizer" (Part No. LUB-FUELC-12-00) to each gallon of fuel.

NOTE:

The use of Yamaha Fuel Conditioner and Stabilizer eliminates the need to drain the fuel system. Consult your Yamaha dealer or other qualified mechanic if the fuel system is to be drained instead.



Flushing Cooling System and Fogging Engine

Cooling system flushing is essential to prevent the cooling system from clogging up with salt, sand, or dirt. In addition, fogging of the engine is mandatory to prevent expensive engine damage due to rust. Perform the flushing and fogging at the same time.

- 1) Remove the top cowl and silencer cover. Remove the propeller.
- 2) Install a flushing attachment to the lower unit. (Flushing attachment available from your Yamaha dealer).

CAUTION

Avoid running the outboard at high rpm while on the flushing attachment or overheating could occur.

WARNING

- Do not touch or remove electrical parts when starting or during operation.
- Keep hands, hair and clothes away from flywheel and other rotating parts while engine is running.

- 3) Run the engine at a fast idle for 10~15 minutes.
- 4) Just prior to turning off the engine, quickly spray "Yamaha Stor-Rite Engine Fogging Oil (Part No. LUB-STRRT-12-00) alternately into each carburetor. When properly done, the engine will smoke excessively and almost stall.
- 5) Remove the flushing attachment and wipe off any excess water.
- 6) Install the silencer cover and top cowl. Install the propeller.



EMK26110*

Lubrication

- 1) Remove the spark plugs, and spray a 10 second spray of Yamaha Stor-Rite Engine Fogging Oil into each cylinder. Grease the spark plug threads and reinstall the spark plugs and torque to proper specification.
(Refer to the Periodic Cleaning and Inspection section, "Cleaning and adjusting spark plug.").
- 2) Turn the engine over with the stop lanyard disconnected to work the fogging oil into the piston rings.
- 3) Fill the oil tanks. This prevents the formation of condensation. For models with a remote tank, it may be necessary to manually override the control unit to completely fill the engine main tank.
(Refer to the Troubleshooting section, "Temporary action in emergency.").
- 4) Change the lower unit oil. (Refer to the Periodic Cleaning and Inspection section, "Changing gear oil."). Inspect the oil for the presence of water which indicates a leaky seal. Seal replacement should be performed by an authorized Yamaha dealership prior to use.
- 5) Grease all grease fittings. (Refer to the Periodic Cleaning and Inspection section, "Greasing.")

EMK27010*

Cleaning and Anti-corrosion Measure

- 1) Wash down the exterior of the outboard with fresh water and dry off completely.
- 2) Spray the engine's exterior with Yamaha Silicone Protectant (Part No. LUB-SILC-NE-13-00).
- 3) Wax the cowling with a non-abrasive wax such as Yamaha Silicone Wax (Part No. ACC-11000-15-02).



EMK28010*

Battery Care**⚠ WARNING**

Battery electrolyte is poisonous and dangerous, causing severe burns, etc. It contains sulfuric acid. Avoid contact with skin, eyes, or clothing.

Antidote:

EXTERNAL; Flush with water.

INTERNAL; Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Call physician immediately.

EYES; Flush with water for 15 minutes and get prompt medical attention.

Batteries produce explosive gases: Keep sparks, flame, cigarettes, etc. away. Ventilate when charging or using in a closed space. Always wear eye protection when working near batteries.

KEEP OUT OF REACH OF CHILDREN.

NOTE:

Batteries vary among manufacturers. Therefore the following procedures may not always apply. Consult your battery manufacturer's instructions.

- 1) Disconnect and remove the battery from the boat. Always disconnect the black negative lead first to prevent the risk of shorting.
- 2) Clean the battery casing and terminals. Fill each cell to the upper level with distilled water.
- 3) Store the battery on a level surface in a cool, dry, well-ventilated place out of direct sunlight.
- 4) Once a month, check the specific gravity of the electrolyte and recharge as required to prolong battery life.



EMK32110

PERIODIC MAINTENANCE

WARNING

Be sure to turn off the engine when you perform maintenance unless otherwise specified. If the owner is not familiar with machine servicing, this work should be done by a Yamaha dealer or other qualified mechanic.

A service manual is available for purchase through a Yamaha dealer for owners who have the mechanical skills, tools, and other equipment necessary to perform maintenance not covered by this owner's manual.

EMK33011

REPLACEMENT PARTS

If replacement parts are necessary, use only genuine Yamaha parts or equivalents of the same type and of equivalent strength and materials. Any part of inferior quality may malfunction, and the resulting loss of control could endanger the operator and passengers.

Yamaha genuine parts and accessories are available from a Yamaha dealer.



EMK30114*

MAINTENANCE CHART

Frequency of maintenance operations may be adjusted according to the operating conditions, but the following table gives general guidelines.

The mark (●) indicates the check-ups which you may carry out yourself.

The mark (○) indicates work to be carried out by your Yamaha dealer.

Interval Item		Initial		Every		Refer page
		10 hours	50 hours (3 months)	100 hours (6 months)	200 hours (1 year)	
Carburetor	Cleaning	○	○	○		—
Fuel filter	Cleaning	●	●	●		4-17
Fuel system	Inspection	●		●		4-16
Fuel tank *2	Cleaning			●		—
Throttle link	Inspection/Adjustment				○	—
Idling speed	Inspection/Adjustment	●		●		4-18
Spark plug	Cleaning/Adjustment/ Replacement	●	●	●		4-14
Oil tank water drain	Cleaning	●	●	●		4-19
Oil pump	Inspection/Adjustment	○				—
Power trim and tilt system *1	Inspection	●	●	●		4-23
Wiring & Connector	Inspection/Reconnect	●	●	●		4-20
Exhaust leakage	Inspection	●	●	●		4-20
Water leakage	Inspection	●	●	●		4-20
Grease points	Greasing			●		4-21
Gear oil	Change	●		●		4-26
Bolts & Nuts	Retightening	●	●	●		4-32
Cowling clamp	Inspection				●	—
Anode	Inspection		●	●		4-27
Propeller	Inspection	●	●	●		4-24
Motor exterior	Inspection	●	●	●		4-32
Cooling water passages *3	Cleaning		●	●		4-9, 4-32
Battery	Inspection	● (every 1 month)				4-28

*1. for Power trim/tilt

*2. If equipped

*3. When operating in salt water, turbid or muddy water, the engine should be flushed with clean water after each use.



EMK36011

CLEANING AND ADJUSTING SPARK PLUG

⚠ WARNING

When removing or installing a spark plug, be careful not to damage the insulator. A damaged insulator could allow external sparks, which could lead to explosion or fire.

The spark plug is an important engine component and is easy to inspect. The condition of the spark plug can indicate something about the condition of the engine. For example, if the center electrode porcelain is very white, this could indicate an intake air leak or carburetion problem in that cylinder. Do not attempt to diagnose any problems yourself. Instead, take the outboard motor to a Yamaha dealer. You should periodically remove and inspect the spark plug because heat and deposits will cause the spark plug to slowly break down and erode. If electrode erosion becomes excessive, or if carbon and other deposits are excessive, you should replace the spark plug with another of the correct type.

Standard spark plug:
Refer to "SPECIFICATIONS", page 4-1.

Before fitting the spark plug, measure the electrode gap with a wire thickness gauge; adjust the gap to specification if necessary.

Spark plug gap:
Refer to "SPECIFICATIONS", page 4-1.



When fitting the plug, always clean the gasket surface and use a new gasket. Wipe off any dirt from the threads and screw in the spark plug to the correct torque.


Spark plug torque:

Refer to "SPECIFICATIONS", page 4-1.

NOTE:

If a torque-wrench is not available when you are fitting a spark plug, a good estimate of the correct torque is 1/4 to 1/2 a turn past finger-tight. Have the spark plug adjusted to the correct torque as soon as possible with a torque-wrench.

Initial of spark plug I.D. mark	Plug wrench size
B	21 mm (13/16 in.)
C	16 mm (5/8 in.)
D	18.3 mm (23/32 in.)



- ① Spark plug gap
② Spark plug I.D. mark (NGK)



EMK38010

CHECKING FUEL SYSTEM

⚠ WARNING

Gasoline (petrol) and its vapors are highly flammable and explosive. Keep away from sparks, cigarettes, flames or other sources of ignition.

Check the fuel line for leaks, cracks, or malfunctions. If any problem is found, it should be repaired immediately by Yamaha dealer or other qualified mechanic.

Checking points



- Fuel system parts leakage.
- Fuel hose joint leakage.
- Fuel hose cracks or other damage.
- Fuel connector leakage.

⚠ WARNING

Leaking fuel can result in fire or explosion.

- Check for fuel leakage regularly.
- If any fuel leakage is found, the fuel system must be repaired by a qualified mechanic.

Improper repairs can make the outboard unsafe to operate.





EMK50011

CLEANING FUEL FILTER


⚠ WARNING

Gasoline (petrol) is highly flammable, and its vapors are flammable and explosive.


- If you have any question about properly doing this procedure, consult your Yamaha dealer.
- Do not perform this procedure on a hot or running engine. Allow the engine to cool.
- There will be fuel in the fuel filter. Keep away from sparks, cigarettes, flames or other sources of ignition.
- This procedure will allow some fuel to spill. Catch fuel in a rag. Wipe up any spilled fuel immediately.
- The fuel filter must be reassembled carefully with O-ring, filter cup, and hoses in place. Improper assembly can result in a fuel leak, which could result in a fire or explosion hazard.

To clean the fuel filter:

- 1) Remove the nut holding the fuel filter assembly if equipped.
- 2) Unscrew the filter cup, catching any spilled fuel in a rag.
- 3) Remove the filter element, and wash it in solvent.
Allow it to dry. Inspect the filter element and O-ring to make sure they are in good condition. Replace them if necessary.

**E**

- 4) Reinstall the filter element in the cup. Make sure the O-ring is in position in the cup. Firmly screw the cup onto the filter housing.
- 5) Attach the filter assembly to the bracket with that the fuel hoses are attached to the filter assembly.
- 6) Run the engine and check the filter and lines for leaks.



- ① Filter element
- ② O-ring
- ③ Filter cap
- ④ Filter housing

EMK54110

ADJUSTING IDLING SPEED

⚠ WARNING


- Do not touch or remove electrical parts when starting or during operation.
- Keep hands, hair and clothes away from flywheel and other rotating parts while engine is running.

CAUTION

This procedure must be performed while the outboard motor is in the water. A flushing attachment or test tank can be used.

**Procedure****NOTE:**

A diagnostic tachometer should be used for this procedure.



- 1) Start the engine and allow it to warm up fully in Neutral until it is running smoothly.

If the outboard is mounted on a boat, be sure the boat is tightly moored.


- 2) Adjust the throttle stop-screw to set the idling speed to specification (see "SPECIFICATIONS") by turning the stop-screw clockwise to increase the idling speed, and turning it counterclockwise to decrease the idling speed.

NOTE:

Correct idling-speed adjustment is only possible if the engine is fully warmed-up. If not warmed up fully, the speed setting will tend to be too high.

If you have difficulty obtaining the specified idle, consult a Yamaha dealer or other qualified mechanic.

- ① Throttle stop-screw




EMK56010

CHECKING WATER TRAP UNDER ENGINE OIL TANK

There is a trap at the bottom of the engine oil tank. If water or foreign matter is visible in this trap, consult a Yamaha dealer.

- ① Trap
② Engine oil tank




EMK76010

REPLACING FUSE (for Electric start model)

If the fuse has blown, open the fuse box and replace the fuse with a new one of the proper amperage.

NOTE:

If the new fuse blows again immediately, consult a Yamaha dealer.




- ① Fuse box
- ② Fuse (20A/30A)

⚠ WARNING

Be sure to use the specified fuse.

A wrong fuse or a piece of wire may allow excessive current flow. This could cause electrical system damage and a fire hazard.



EMK78010

CHECKING WIRING AND CONNECTORS

- 1) Check that each grounding wire is properly secured.
- 2) Check that each connector is engaged securely.

EXHAUST LEAKAGE

Start the engine and check that no exhaust leaks from the joints between the exhaust cover, cylinder head and crank case.

WATER LEAKAGE


Start the engine and check that no water leaks from the joints between the exhaust cover, cylinder head and crank case.

**E**

EML00010

GREASING

Yamaha marine grease A
(Water-resistant grease)

V4




E


EML00010

GREASING

Yamaha marine grease A
(Water-resistant grease)

V6






EML02011*

CHECKING POWER TRIM AND TILT SYSTEM

⚠ WARNING

- Never get under the lower unit while it is tilted, even when the tilt-support lever is locked. Severe injury could occur if the outboard accidentally falls.
- Make sure no one is under the outboard before performing this test.



- 1) Check the power trim and tilt unit for any sign of oil leaks.
- 2) Operate each of the power trim and tilt switches on remote control and engine bottom cowling (if equipped) to check that all switches work.
- 3) Tilt up the motor and check that the tilt rod and trim rods are pushed out completely.
- 4) Use the tilt-support lever to lock the motor in the UP position. Operate the tilt down switch briefly so the motor is supported the tilt-support lever.
- 5) Check that the tilt rod and trim rods are free of corrosion or other flaws.
- 6) Activate the tilt-down switch until the trim rods have gone completely into the cylinders.
- 7) Activate the trim-up switch until the tilt rod is fully extended. Unlock the tilt-support lever.
- 8) Operate the motor to tilt down. Check that the tilt rod and trim rods operate smoothly.

NOTE:

If any operation is abnormal, consult a Yamaha dealer.

Recommended fluid; Yamaha power trim & tilt fluid or ATF (DEXRON-II).






EML08210

CHECKING PROPELLER


⚠ WARNING

You could be seriously injured if the engine accidentally starts while you are near the propeller.

- Before inspecting, removing or installing the propeller, remove the spark plug caps from the spark plugs. Also, put the shift control in Neutral, put the main switch in the OFF position and remove the key, and remove the lanyard from the engine stop switch. Turn off the battery cut-off switch if your boat has one.
- Do not use your hand to hold the propeller when loosening or tightening the propeller nut. Put a wood block between the cavitation plate and the propeller to prevent the propeller from turning.



- 1) Check each of the propeller blades for wear, erosion from cavitation or ventilation, or other damage.
- 2) Check the splines for wear and damage.
- 3) Check for fish line winding around the propeller shaft.
Check the propeller shaft oil seal for damage.

**[How to remove propeller]**

- 1) Using the pliers provided, straighten the cotter-pin and pull it out.
- 2) Remove the propeller nut.
- 3) Remove the propeller.

- | | |
|-----------------|-----------------|
| ① Thrust washer | ④ Washer |
| ② Propeller | ⑤ Propeller nut |
| ③ Spacer | ⑥ Cotter pin |

[How to install propeller]

- 1) Apply Yamaha Marine grease A or Marine grease (water-resistant grease) to the propeller-shaft.
- 2) Slide the propeller over the propeller-shaft.

CAUTION:

Be sure to install the thrust washer before installing propeller, otherwise, lower case and propeller boss may be damaged.

- 3) Tighten the propeller nut to the specified torque.

Tightening torque:

Refer to "SPECIFICATIONS", Page 4-1.


- 4) Align the propeller nut with the propeller shaft hole. Insert a new cotter pin in the hole and bend the cotter pin ends.

NOTE:

When the propeller nut does not align with the propeller shaft hole after tightening to the specified torque, then tighten it more to align the hole.

CAUTION:

Be sure to use a new cotter pin and bend the ends over securely. Otherwise, the propeller could come off during operation and be lost.



602053



EML20010

CHANGING GEAR OIL

⚠ WARNING

Never get under the lower unit while it is tilted, even when the tilt- support lever is locked. Severe injury could occur if the outboard accidentally falls.

- 1) Put the outboard in a vertical position (not tilted).

⚠ WARNING

Be sure the outboard is securely fastened to the transom or a stable stand. You could be severely injured if the outboard falls on you.


- 2) Place a suitable container under the gearcase.
- 3) Remove the oil drain plug.

NOTE:

The oil drain plug is magnetic. Remove all metal particles from the plug before re-installing it.

- 4) Remove the oil level plug to allow the oil to drain completely.

- ① Oil-level plug
- ② Oil drain-plug




CAUTION

Inspect the used oil after it has been drained. If the oil is milky, water is getting into the gearcase which can cause gear damage. Consult a Yamaha dealer for repair of the lower unit seals.

NOTE:


For disposal of used oil consult your Yamaha dealer.



- 5) With the outboard motor in an vertical position, using a flexible or pressurized filling device, inject outboard motor hypoid gear oil (SAE 90) into the oil drain plug hole.

Gear oil capacity:
Refer to "SPECIFICATIONS", Page 4-1.

- 6) When oil begins to flow out of the oil level plug hole, insert and tighten the oil level plug.
- 7) Insert and tighten in the oil drain plug.




EML24010

INSPECTING AND REPLACING ANODE

Yamaha outboard motor is protected from corrosion by sacrificial anode.

Check the anode periodically. Remove the scales from surfaces of the anode.

For the replacement of the anode, consult a Yamaha dealer.



CAUTION:

Do not paint the anode, for this would render it ineffective.



EML26010

CHECKING BATTERY **(for Electric start model)**

⚠ WARNING

Battery electrolytic fluid is dangerous; it contains sulfuric acid and therefore is poisonous and highly caustic.

Always follow these preventive measures:

- Avoid bodily contact with electrolytic fluid as it can cause severe burns or permanent eye injury.
- Wear protective eye gear when handling or working near batteries.

Antidote (EXTERNAL):

- SKIN—Flush with water.
- EYES—Flush with water for 15 minutes and get immediate medical attention.

Antidote (INTERNAL):

- Drink large quantities of water or milk followed by milk of magnesia, beaten egg, or vegetable oil. Get immediate medical attention.

Batteries also generate explosive hydrogen gas; therefore, you should always follow these preventive measures:

- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks, or open flames (e.g., welding equipment, lighted cigarettes, etc.).
- DO NOT SMOKE when charging or handling batteries.
- KEEP BATTERIES AND ELECTROLYTIC FLUID OUT OF REACH OF CHILDREN.

**CAUTION:**

A poorly maintained battery will quickly deteriorate.

- 1) Check the electrolyte level at least once a month. Fill to the manufacturer's recommended level when necessary.
Top-up only with distilled water (or pure de-ionized water suitable to use in batteries).

CAUTION:

Ordinary tap-water contains minerals harmful to a battery, and should not be used for topping-up.

- 2) Keep the battery always in a good state of charge. Installing a voltmeter will help you monitor your battery.
If you will not use the boat for a month or more, remove the battery from the boat and store it in a cool, dark place.
Completely recharge the battery before using it.
- 3) If the battery will be stored for longer than a month, check the specific gravity of the fluid at least once a month and recharge the battery when it is low.




EML28210

Connecting the battery

⚠ WARNING

Mount the battery holder securely in a dry, well-ventilated, vibration-free location in the boat. Install the fully charged battery in the holder.



Connect the RED lead to the POSITIVE (+) terminal first.

Then connect the BLACK lead to the NEGATIVE (-) terminal.


- ① Red lead
- ② Black lead
- ③ Battery

Disconnecting the battery

Disconnect the BLACK lead from the NEGATIVE (-) terminal first. Then disconnect the RED lead from the POSITIVE (+) terminal.

CAUTION

- Make sure the main switch (on applicable models) is OFF before working on the battery.
- Reversal of the battery leads will damage the rectifier.
- Connect the RED lead first when installing the battery and disconnect the RED lead last when removing it. Otherwise, the electrical system can be damaged.
- The electrical contacts of the battery and cables must be clean and properly connected, or the battery will not start the engine.



Using a single battery (for V6 engine type)

Connect both red cables (① & ②) to the (+) terminal.

⚠WARNING

Do not leave cable ② unconnected. If it accidentally contacts the **NEGATIVE (-) terminal** of the battery, there will be a short circuit. Electrical system damage and a fire could result.

- ① Large red lead for starting battery
- ② Small red lead for accessory battery charging
- ③ Large black lead
- ④ Battery

Using an accessory battery (for V6 engine type)

Use a connecting cable between the (-) terminals of the starting battery and accessory battery. See the illustrations of the wiring connections.


This cable must be made from wire equivalent to the starting battery cable ③.

⚠WARNING

Use of smaller wire could lead to a fire.

NOTE:

If a battery selector switch is desired, consult your YAMAHA dealer about correct wiring.




- ① Battery for starting
- ② Battery for accessories
- ③ Large red lead for starting battery
- ④ Small red lead for accessory battery charging
- ⑤ Large black lead
- ⑥ Negative connecting cable



EML40010

CHECKING BOLTS AND NUTS

- 1) Check that bolts securing the cylinder head and engine and the nut securing the flywheel are tightened with their specified tightening torques.
- 2) Check the tightening torques of other bolts and nuts.



EML42111

MOTOR EXTERIOR**Cleaning the Outboard Motor**

After use, wash the exterior of the outboard with fresh water. Flush the cooling system with fresh water.


Cleaning cooling-water passages

NOTE: _____
Refer to cooling system flushing instructions in "TRANSPORTING AND STORING OUTBOARD MOTOR".

Flushing device equipped model

NOTE: _____
For the most thorough flushing, perform this procedure right after operation.

- 1) After shut off the engine, tilt the engine up. Unscrew the garden-hose connector from the fitting on the bottom cowling.
- 2) Screw the garden-hose connector onto a garden hose which is connected to a fresh-water supply.
- 3) With the engine off, open the water tap and let the water flush through the cooling passages for about 15 minutes. Turn off the water and disconnect the garden hose.



- 4) When flushing is complete, reinstall the garden-hose connector on the fitting on the lower cowling. Tighten securely.


CAUTION

Do not leave the garden-hose connector loose on the lower-cowling fitting or let the hose hang free during normal operation. Water will leak out of the connector instead of cooling the engine, which can cause serious overheating. Be sure the connector is tightened securely on the fitting after flushing the engine.

- ① Bottom cowling fitting
- ② Garden hose connector
- ③ Garden hose

Checking Painted Surface of Motor

Check the motor for scratches, nicks, or flaking paint. Areas with damaged paint are more likely to corrode. If necessary, clean and paint the areas. Consult a Yamaha dealer for touch-up paint.



EML44010

COATING THE BOAT BOTTOM

A clean hull improves boat performance. The boat bottom should be kept as clean of marine growths as possible. If necessary, the boat bottom can be coated with an anti-fouling paint approved for your area to inhibit marine growth. Do not use anti-fouling paint which includes copper or graphite. These paints can cause more rapid engine corrosion.

EMN00010

Chapter 5

TROUBLE RECOVERY

TROUBLESHOOTING5-1

TEMPORARY ACTION

IN EMERGENCY5-5

Impact damage5-5

Power trim / tilt will not operate5-5

Starter will not operate5-6

Engine fails to operate5-8

Low oil level warning works5-9

Top cowling does not unlock5-10

Treatment of submerged motor5-11





TROUBLESHOOTING

Trouble	Possible Cause	Remedy
A. Starter will not operate	1. Battery capacity weak or low 2. Battery connections loose or corroded 3. Fuse for electric start circuit blown 4. Starter components faulty 5. Engine stop switch lanyard not attached 6. Shift lever is gear-in position	1. Check battery condition. Use battery of recommended capacity. 2. Tighten battery cables and clean battery terminals. 3. Check for cause of electric overload and repair. Replace fuse with one of correct amperage. 4. Have Yamaha dealer service. 5. Attach lanyard. 6. Position to neutral.
B. Engine will not start (Starter operates)	1. Fuel tank empty 2. Fuel contaminated or stale 3. Fuel filter clogged 4. Starting procedure is wrong 5. Fuel pump malfunctions 6. Spark plug(s) fouled or wrong type 7. Spark plug cap(s) fitted incorrectly 8. Poor connections or damaged ignition wiring 9. Ignition parts faulty 10. Engine stop switch lanyard not attached 11. Shift lever is gear-in position 12. Engine inner parts damaged	1. Fill tank with clean, fresh fuel. 2. Fill tank with clean, fresh fuel. 3. Clean or replace it. 4. Read "STARTING ENGINE" section. 5. Have Yamaha dealer service. 6. Inspect spark plug(s). Clean or replace with recommended type. 7. Check and re-fit cap(s). 8. Check wires for wear or breaks. Tighten all loose connections. Replace worn or broken wires. 9. Have Yamaha dealer service. 10. Attach lanyard. 11. Position to neutral. 12. Have Yamaha dealer service.



Trouble	Possible Cause	Remedy
C. Engine idles irregularly or stallse	1. Spark plug(s) fouled or wrong type 2. Fuel system obstructed 3. Fuel contaminated or stale 4. Fuel filter clogged 5. Failed ignition parts 6. Warning system activated 7. Spark plug gap incorrect 8. Poor connections or damaged ignition wiring 9. Specified engine oil not used 10. Thermostat faulty or clogged 11. Carburetor adjustments incorrect 12. Fuel pump damaged 13. Air vent screw on the fuel tank is closed 14. Choke knob is pulled out 15. Motor angle is too high 16. Carburetor is clogged 17. Fuel joint connection is wrong 18. Throttle valve adjusts incorrect 19. Battery lead is removed	1. Inspect spark plug(s). Clean or replace with recommended type. 2. Check for pinched or kinked fuel line or other obstructions in fuel system. 3. Fill tank with clean, fresh fuel. 4. Clean or replace filter. 5. Have Yamaha dealer service. 6. Find and correct cause. 7. Inspect and adjust as specified. 8. Check wires for wear or breaks. Tighten all loose connections. 9. Check and replace it as specified. 10. Have Yamaha dealer service. 11. Have Yamaha dealer service. 12. Have Yamaha dealer service. 13. Open the air vent screw. 14. Return to home position. 15. Return to normal operating position. 16. Have Yamaha dealer service. 17. Connect correctly. 18. Have Yamaha dealer service. 19. Connect securely.



Trouble	Possible Cause	Remedy
D. Warning buzzer sounds or indicator lamp lights.	1. Cooling system clogged 2. Engine oil level low 3. Heat range of spark plug incorrect 4. Specified engine oil not used 5. Engine oil contaminated or deteriorated 6. Oil filter clogged 7. Oil feed/injection pump malfunctions 8. Load on boat improperly distributed even plane. 9. Water pump/thermostat faulty	1. Check water intake for restriction. 2. Fill oil tank with specified engine oil. 3. Check the plug condition and replace it with a correct type. 4. Check and replace oil with specified type. 5. Replace oil with fresh, specified type. 6. Have Yamaha dealer service. 7. Have Yamaha dealer service. 8. Distribute load to place boat on an 9. Have Yamaha dealer service.
E. Engine power loss	1. Propeller damaged 2. Propeller pitch or diameter wrong 3. Trim angle incorrect 4. Motor mounted at wrong height on transom 5. Warning system activated 6. Boat bottom fouled with marine growth 7. Spark plug(s) fouled or wrong type 8. Weeds or other foreign matters tangled on gear housing 9. Fuel system obstructed 10. Fuel filter clogged 11. Fuel contaminated or stale 12. Spark plug gap incorrect	1. Have propeller repaired or replaced. 2. Install correct propeller to operate outboard at its recommended r/min range. 3. Adjust trim angle to gain most efficient operation. 4. Have motor adjusted to proper transom height. 5. Find and correct cause. 6. Clean boat bottom. 7. Inspect spark plug(s). Clean or replace with recommended type. 8. Remove them and clean lower unit. 9. Check for pinched or kinked fuel line or other obstructions in fuel system. 10. Clean or replace filter. 11. Fill tank with clean, fresh fuel. 12. Inspect and adjust as specified.



Trouble	Possible Cause	Remedy
E. Engine power loss	13. Poor connections or damaged ignition wiring 14. Failed ignition parts 15. Specified engine oil not used 16. Thermostat faulty or clogged 17. Air vent screw is closed 18. Fuel pump damaged 19. Fuel joint connection is wrong 20. Heat range of spark plug incorrect	13. Check wires for wear or breaks. Tighten all loose connections. Replace worn or broken wires. 14. Have Yamaha dealer service. 15. Check and replace it as specified. 16. Have Yamaha dealer service. 17. Open the air vent screw. 18. Have Yamaha dealer service. 19. Connect correctly. 20. Check the plug condition and replace it with a correct one.
F. Engine vibrates excessively	1. Propeller damaged 2. Propeller shaft damaged 3. Weeds or other foreign matter tangled on propeller 4. Motor mounting bolt is loosen 5. Steering pivot is loosen or damaged	1. Have propeller repaired or replace. 2. Have Yamaha dealer service. 3. Remove and clean propeller. 4. Tighten the bolt. 5. Tighten or have Yamaha dealer service.



EMN20010


TEMPORARY ACTION IN EMERGENCY

EMH80010

IMPACT DAMAGE

⚠ WARNING

The outboard motor can be seriously damaged by a collision while operating or trailering. Damage could make the outboard motor unsafe to operate.



If the outboard motor hits any object in the water, follow the procedure below;

- 1) Stop the engine immediately .
- 2) Inspect control system and all components for damage. Also, inspect the boat damage .
- 3) However damage is found or not found, go back to a nearest harbor slowly and carefully.
- 4) Have a Yamaha dealer inspection of the outboard motor, before operating it again.

EMG65210


POWER TRIM / TILT WILL NOT OPERATE

If the engine cannot be tilted up or down with the power trim and tilt because of a discharged battery or a failure with the power trim and tilt unit, the engine can be tilted manually.

- ① Manual valve screw

EMG65111

- 1) Loosen the manual valve screw counterclockwise until it stops.
- 2) Put the engine in the desired position, then tighten the manual valve screw clockwise.



411025




EMN30210

STARTER WILL NOT OPERATE


If the starter mechanism does not operate (engine cannot be cranked with the starter), the engine can be started with an emergency starter rope.

⚠ WARNING


- Use this procedure only in an emergency and only to return to port for repairs.
- When the emergency starter rope is used to start the engine, the start-in-gear protection device does not operate. Make sure the transmission is in neutral. Otherwise, the boat could unexpectedly start to move, which could result in an accident.
- Be sure no one is standing behind you when pulling the starter rope. It could whip behind you and injure someone.
- An unguarded rotating flywheel is very dangerous. Keep loose clothing and other objects away when starting the engine. Use the emergency starter rope only as instructed. Do not touch the flywheel or other moving parts when the engine is running. Do not install the starter mechanism or top cowling after the engine is running.
- Do not touch the ignition coil, high voltage wire, spark plug cap or other electrical components when starting of operating the motor. You could be shocked.

**Procedure**



- 1) Remove the top cowling.
- 2) Remove the flywheel cover by removing the bolts.
- 3) Prepare the engine for starting. See STARTING ENGINE for procedures. Be sure the engine is in Neutral and that the lanyard is attached to the engine stop switch. The main switch must be on.

**NOTE:**

- In this case, choke switch will not operate. Pull out the choke knob when engine is cold.
 - Without setting the main switch to ON, it is impossible to start the engine.
- 4) To start the engine with the emergency starter rope, insert the knotted end of the rope into the notch in the flywheel rotor and wind the rope several turns clockwise. Then, give a strong pull straight out to crank the engine. Repeat if necessary.

**⚠ WARNING**

Do not install the top cowling when engine is running.



EMN32110

ENGINE FAILS TO OPERATE

If battery voltage is low or in the unlikely event of an ignition system malfunction, the engine speed may become erratic or the engine may stop. In such a case, disconnect the connection on the yellow cord (emergency circuit) to return to port.

⚠ WARNING

When the connection is disconnected, the idling and low speeds are slightly higher than normal. Use care when starting off or stopping.


- ① CDI unit
- ② Yellow cord

CAUTION:

Follow this procedure only in an emergency and just long enough to return to port for repairs.



V4



EMD34011*

LOW OIL LEVEL WARNING WORKS

If the oil level is allowed to drop too low, the red segment will appear on the oil level indicator, the buzzer will sound, and engine speed will be limited to about 2,000 r/min. If this happens, a reserve amount of oil can be pumped from the remote oil tank (3) to the engine oil tank (2) using the emergency switch (1).



⚠ WARNING

Be sure to stop the engine before performing this procedure.

CAUTION:

- If the emergency switch is held up too long, too much oil will be pumped into the engine tank, overflowing it. Release the switch when oil reaches the upper level line on the engine oil tank.
- Do not use this emergency procedure unless the oil level warning lamps are installed and working.


V6



- 1) Remove the top cowling.
- 2) Turn the main switch to the "ON" position.
- 3) Lift the emergency switch to pump reserve oil in remote oil tank into the engine oil tank.
- 4) After using the emergency switch, turn off the main switch, then turn it back on. This resets the warning system for normal operation. Yellow segment will remain appearing on oil level indicator at this time.
- 5) Start the engine and return to the nearest port for more oil.

**NOTE:**

- Reserve oil capacity is maximum 1,500 cm³ (1.6 US qt, 1.31 Imp qt).
- The oil feed pump will not operate if the engine is tilted more than 35°. Put the engine in the down position before operating the emergency switch.



EMD64111*

TOP COWLING DOES NOT UNLOCK

If the top cowling stays locked when the release lever is operated, the cable may be damaged or misadjusted.

- 1) Pull the cowling release lever ① to unlock the front lock.
- 2) Pull the emergency cowling release wire ② coming out of the hole on the side of the pilot hole in the bottom cowling to release the port side rear lock.
- 3) Lift the port side of the top cowling to pull out the emergency cowling release wire ③ from the port side of the bottom cowling.
- 4) Pull the emergency cowling release wire ③ to release the starboard side rear lock.

CAUTION:

Be sure the problem with the cowling lock is repaired before reinstalling the cowling.



EMN50011




TREATMENT OF SUBMERGED MOTOR

If the outboard motor is submerged, immediately take it to a Yamaha dealer. Otherwise, some corrosion may begin almost immediately. If you cannot immediately take the outboard motor to a Yamaha dealer, follow the procedure below for taking care to minimize engine damage.

- 1) Thoroughly wash away mud, salt, seaweed, etc. with fresh water.
- 2) Remove the spark plugs, and face the spark plug holes downward to allow any water, mud or contaminants to drain.
- 3) Drain the fuel from the carburetor.
- 4) Feed fogging oil or engine oil through the carburetors and spark plug holes while cranking with the manual starter or emergency starter rope.
- 5) Take the outboard motor to a Yamaha dealer as soon as possible.

CAUTION

Do not attempt to run the motor until it has been completely inspected.




EMP00010

Chapter 6

INDEX

INDEX6-1

A to Z



EMR80000

INDEX

A

Adjusting idling speed4-18

Adjusting trim angle3-20

B

Basic boating rules1-6

Battery care4-11

Battery requirement1-12

Breaking in (running in) engine3-9

C

Changing gear oil4-26

Checking battery4-28

Checking bolts and nuts4-32

Checking fuel system4-16

Checking painted surface of motor4-33

Checking power trim and tilt system4-23

Checking propeller4-24

Checking water trap under engine oil
tank4-19

Checking wiring and connectors4-20

Choke knob2-3

Choke switch2-6

Cleaning and adjusting spark plug4-14

Cleaning and anti-corrosion
measure4-10

Cleaning cooling-water passages4-32

Cleaning fuel filter4-17

Cleaning the outboard motor4-32

Clock2-15

Coating boat bottom4-33

Connecting the battery4-30

Cruising in other conditions3-25

Cruising in salt water3-25

Cruising in turbid water3-25

D

Digital speedometer2-13

Digital tachometer2-12

Disconnecting the battery4-30

Dual engine installation/single engine
running3-22**E**

Emission control information1-2

Engine fails to operate5-8

Engine oil1-11

Engine stop lanyard switch2-7

Exhaust leakage4-20

F

Filling fuel3-4

Filling fuel and engine oil3-4

Filling oil3-5

Flushing cooling system and fogging
engine4-9

Forward3-17

Free accelerator2-9

Fuel consumption meter2-17

Fuel economy2-18

Fuel flow meter2-17

Fuel management meter2-16

Fuel meter2-15

Fueling instructions1-10

G

Gasohol1-11

Gasoline (Petrol)1-10

Greasing4-21

I

Identification numbers record1-1

Impact damage5-5

Important labels1-5

Index6-1

Inspecting and replacing anode4-27

Installation3-1

K

Key number1-1

L

Low oil lever warning works5-9

M

Main components2-1

Main switch2-6

Maintenance chart4-13

Motor exterior4-32

Mounting height3-3

Mounting the outboard motor	3-2	Throttle friction adjusting screw	2-9
N		Tilt support lever	2-20
Neutral interlock trigger	2-5	Tilting up/down	3-23
Neutral throttle lever	2-5	Top cowling does not work	5-10
O		Top cowling lock levers	2-20
Oil level indicator	3-6	Top cowling release lever	2-21
Oil-level warning indicator	2-12	Trailing outboard motor	4-7
Oil level warning/oil filter clogging warning	2-23	Transporting and storing outboard motor	4-7
Operation after a long period of storage	3-8	Treatment of submerged motor	5-11
Operations of controls and other functions	2-3	Trim meter	2-12
Outboard motor serial number	1-1	Trim tab	2-10
Overheat warning	2-22	Trimming outboard motor	3-19
Overheat warning indicator	2-13	Trip meter	2-14
P		Troubleshooting	5-1
Periodic maintenance	4-12	Twin engine speed synchronizer	2-19
Power trim / tilt will not operate	5-5	U	
Power trim and tilt switch	2-8, 2-11	Using a single battery	4-31
Pre-operation check	3-7	Using an accessory battery	4-31
Propeller selection	1-12	W	
R		Warming up engine	3-16
Remote control	2-4	Warning indicator	2-16
Remote control lever	2-5	Warning system	2-22
Replacement parts	4-12	Warranty information	Next page
Replacing fuse	4-20	Water leakage	4-20
Reverse	3-17	Water separator warning indication	2-19
S			
Safety information	1-3		
Shifting	3-17		
Specification data	4-1		
Speedometer	2-14		
Start-in-gear protection	2-3		
Starter will not operate	5-6		
Starting engine	3-11		
Stopping engine	3-18		
Storing outboard motor	4-8		
T			
Tachometer	2-12		
Temporary action in emergency	5-5		

IMPORTANT WARRANTY INFORMATION FOR U.S.A. AND CANADA

Welcome to the Yamaha Family!

Congratulations on the purchase of your new Yamaha marine power. Yamaha is committed to exceptional customer satisfaction, and we want your ownership experience to be a satisfying one. Please read the following warranty information to help ensure satisfaction with your Yamaha.

Yamaha is ready to stand behind your purchase with strong warranty coverage. To be sure you receive all the benefits of warranty, please take the following steps:

1. Be sure your new Yamaha is registered for warranty. Your boat dealer should do this at the time of sale. Make sure your dealer gives you a copy of the completed Yamaha registration card for your records. If you are unsure whether or not your Yamaha is registered, complete the Warranty Registration card found inside the cover of the Owner's Manual. Mail it to the distributor for the country in which you live (see step 6 for the correct address). If your Yamaha is not properly registered, a warranty repair could be unnecessarily delayed while registration records are checked.
2. Read the Limited Warranty statement which follows these instructions. This warranty applies to Yamaha outboard motors sold in the United States, whether purchased separately or when supplied as original equipment by a boat builder. The terms also apply to original equipment packages sold in Canada, with coverage provided by Yamaha Motor Canada (see "Warranty Guide" for Canadian models). This warranty explains the conditions of the warranty, including the obligations that your dealer and you as the owner have under the warranty. For example, your Yamaha outboard must receive a proper predelivery inspection (PDI) by the selling dealer. Failure to take this important step could jeopardize warranty coverage!
3. If you need warranty repairs, you must take your Yamaha outboard to an authorized Yamaha outboard dealer. Be aware that not all selling boat dealers are authorized Yamaha dealers. Only authorized dealers have the factory training, special tools, and Yamaha support needed to perform warranty repairs.
4. If you are away from home, or your selling dealer is not an authorized Yamaha dealer, use the following toll-free numbers to find the nearest Yamaha dealer.

United States Dealer Locations: 1-800-447-4700

Canada Dealer Locations: 1-800-267-8577

5. Your warranty applies specifically to repairs made in the country of purchase. If your U.S.-purchased Yamaha needs warranty service while in Canada, or your Canadian purchased Yamaha needs service while in the United States, Yamaha will assist the local dealer whenever possible. However, some products available in one country may not be sold or serviced in the other.
6. If you need any additional information about your Yamaha or warranty coverage which your dealer cannot provide, please contact us directly.

Yamaha Motor Corporation, U.S.A.
P.O. Box 6555
Cypress, CA 90630
Attention: Customer Relations Department

Telephone No. (714) 761-7439
Fax No. (714) 761-7559

Yamaha Motor Canada Ltd.
480 Gordon Baker Road
North York, Ontario
M2H 3B4
Attention: Customer Relations Department

Telephone No. (416) 498-1911
Fax No. (416) 491-3122

YAMAHA MOTOR CORPORATION, U.S.A. OUTBOARD MOTOR TWO YEAR LIMITED WARRANTY

Yamaha Motor Corporation, U.S.A. is proud of its heritage and reputation for producing products with high standards of quality and workmanship. Product excellence provides the cornerstone for our commitment to customer satisfaction. The Yamaha Outboard Limited Warranty is your assurance of this commitment.

This warranty provides you with protection against the expense of repairs for your outboard motor that are required as a result of defects in materials or workmanship. When maintained and utilized in the prescribed manner, you can count on your Yamaha outboard to provide reliable service.

This warranty provides you with specific coverage and notes your responsibilities in maintaining and operating your outboard. Please take the time to read and become familiar with this warranty.

PERIOD OF WARRANTY. Any new Yamaha outboard motor purchased and registered with Yamaha Motor Corporation, U.S.A. for pleasure use in the United States, will be warranted against defects in material or workmanship for a period of two (2) years from date of purchase, subject to exclusions noted herein. Any Yamaha outboard motor purchased and utilized for commercial applications will be warranted for a period of one (1) year from the date of purchase, subject to exclusions noted herein. Yamaha peripheral equipment included with the motor, such as gauges, fuel tanks and hoses, remote control boxes, propellers, and wiring external from the motor unit, will be warranted for one (1) year from the date of purchase for either pleasure or commercial use. Replacement parts used in warranty repairs will be warranted for the balance of the applicable warranty period.

The second year of warranty (if applicable) shall be limited to covering the cost of parts and labor for major components only. The major components covered are:

Power Unit Section

- Power Head
- Intake Manifold and Reed Valve Assembly
- Carburetor Assembly and its Related Components
- Fuel and Oil Pump Assemblies
- Ignition System (Standard and Microcomputer)
- Precision Blend® Reg System

Bracket Section

- Bracket System
- Power Trim and Tilt Assembly

Lower Unit Section

- Exhaust System
- Upper Casing
- Lower Unit Assembly

The warranty described here applies to outboard motor purchased and registered for use in the United States only excluding its territories. For warranty provisions outside the United States, contact the particular country's local Yamaha distributor.

WARRANTY REGISTRATION. To be eligible for warranty coverage, the outboard motor must first be registered with Yamaha Motor Corporation, U.S.A. A warranty registration form is provided in the Owner's Manual with each outboard. This form must be completed and mailed to Yamaha by either the selling dealer or the purchaser. Warranty registration can also be accomplished by any authorized Yamaha outboard dealer. Upon receipt of the registration, an Owner's Warranty Card will be sent by Yamaha to the registered purchaser.

OBTAINING REPAIRS UNDER WARRANTY. To receive repairs under this warranty, a valid Owner's Warranty Card must be presented to an authorized Yamaha outboard dealer.

During the period of warranty, any authorized Yamaha outboard dealer will, free of charge, repair or replace, at Yamaha's option, any parts adjudged defective by Yamaha due to faulty workmanship or material from the factory. All replaced parts will become the property of Yamaha Motor Corporation, U.S.A.

CUSTOMER'S RESPONSIBILITY. Under the terms of this warranty, the customer will be responsible for ensuring that the outboard motor is properly operated, maintained and stored as specified in the applicable Owner's Manual.

The owner of the outboard motor shall give notice to an authorized Yamaha marine dealer of any and all apparent defects within ten (10) days of discovery and make the motor available at that time for inspection and repairs at the dealer's place of business.

GENERAL EXCLUSIONS FROM WARRANTY. This warranty will not cover the repair of damage if the damage is a result of abuse or neglect of the product. Examples of abuse and neglect include, but are not limited to:

1. Racing or competition use, modification of original parts, abnormal strain.
2. Lack of proper maintenance and off-season storage as described in the Owner's Manual, improper mounting of the motor, installation of parts or accessories that are not equivalent in design and quality to genuine Yamaha parts.
3. Operation of the motor at an rpm other than specified, improper propeller selection, use of lubricants, oils, and fuel/oil mixtures that are not suitable for outboard motor use.
4. Damage as a result of accidents, collisions, contact with foreign materials, or submersion.
5. Growth of marine organisms on motor surfaces.
6. Normal deterioration.

SPECIFIC PARTS EXCLUDED FROM WARRANTY. Parts replaced due to normal wear or routine maintenance such as oil, spark plugs, shear pins, propellers, hubs, fuel and oil filters, brushes for the starter motor and power tilt motor, water pump impellers, and anodes are not covered by warranty. Charges for removal of the motor from a boat and transporting the motor to and from an authorized Yamaha outboard dealer are excluded from warranty coverage.

Specific parts excluded from the second year of warranty (if applicable) are:

- Top and Bottom Cowling
- Electric Components (other than ignition system)
- Rubber Components (such as hoses, tubes, rubber seals, fittings, and clamps)

TRANSFER OF WARRANTY. Transfer of the warranty from the original purchaser to any subsequent purchaser is possible by having the motor inspected by an authorized Yamaha outboard dealer and requesting the dealer to submit a change of registration to Yamaha Motor Corporation, U.S.A. within ten (10) days of the transfer.

YAMAHA MOTOR CORPORATION, U.S.A. MAKES NO OTHER WARRANTY OF ANY KIND, EXPRESSED OR IMPLIED. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE WHICH EXCEED THE OBLIGATIONS AND TIME LIMITS STATED IN THIS WARRANTY ARE HEREBY DISCLAIMED BY YAMAHA MOTOR CORPORATION, U.S.A. AND EXCLUDED FROM THIS WARRANTY.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. ALSO EXCLUDED FROM THIS WARRANTY ARE ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING LOSS OF USE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

YAMAHA MOTOR CORPORATION, U.S.A.
Post Office Box 6555
Cypress, California 90630

WARRANTY QUESTIONS AND ANSWERS

- Q. What costs are my responsibility during the warranty period?
- A. The customer's responsibility includes all costs of normal maintenance services, non-warranty repairs, accident and collision damages.
- Q. What are some examples of "abnormal" strain, neglect, or abuse?
- A. These terms are general and overlap each other in areas. Specific examples include:
Running the machine out of oil, operating the machine with a broken or damaged part which causes another part to fail, damage or failure due to improper or careless transportation, and/or tie down. If you have any specific questions on operation or maintenance, please contact your Yamaha outboard dealer for advice.
- Q. Does the warranty cover incidental costs such as towing or transportation due to a failure?
- A. No. The warranty is limited to repair of the machine itself.
- Q. May I perform any or all of the recommended maintenance shown in the Owner's Manual instead of having the dealer do them?
- A. Yes, if you are a qualified mechanic and follow the procedures specified in the Owner's and Service Manuals. We do recommend, however, that items requiring special tools or equipment be done by a Yamaha outboard dealer.
- Q. Will the warranty be void or canceled if I do not operate or maintain my new outboard exactly as specified in the Owner's Manual?
- A. No. The warranty on a new outboard cannot be "voided" or "cancelled". However, if a particular failure is caused by operation or maintenance other than as shown in the Owner's Manual, that failure may not be covered under warranty.
- Q. What responsibility does a Yamaha outboard dealer have under this warranty?
- A. Each Yamaha outboard dealer is expected to:
1. Completely set up each outboard he sells prior to delivery.
 2. Explain the operation, maintenance, and warranty requirements to your satisfaction at the time of sale, and upon your request at any later date.
- In addition, each Yamaha outboard dealer is held responsible for his setup, service and warranty repair work.
- Q. Is the warranty transferable to second owners?
- A. Yes. The remainder of any existing warranty can be transferred upon request. The unit has to be inspected and re-registered by an authorized Yamaha outboard dealer for the policy to remain effective.

CUSTOMER SERVICE

If your machine requires warranty service, you must take it to any authorized Yamaha outboard dealer within the continental United States. Be sure to bring your warranty registration identification or other valid proof of the original date of purchase. If a question or problem arises regarding warranty, first contact the owner of the dealership. Since all warranty matters are handled at the dealer level, this person is in the best position to help you. If you are still not satisfied and require additional assistance, please write:

YAMAHA MOTOR CORPORATION U.S.A.
CUSTOMER RELATIONS DEPARTMENT
P.O.Box 6555
Cypress, California 90630

When contacting Yamaha Motor Corporation, U.S.A. don't forget to include any important information such as names, addresses, model, engine serial number, dates, and receipts.

CHANGE OF ADDRESS

The federal government requires each manufacturer of a motor vehicle to maintain a complete, up-to-date list of all first purchasers against the possibility of a safety-related defect and recall. This list is compiled from the purchase registrations sent to Yamaha Motor Corporation, U.S.A. by the selling dealer at the time of your purchase.

If you should move after you have purchased your new outboard, please advise us of your new address by sending a postcard listing your outboard model name, engine serial number, dealer number (or dealer's name) as it is shown on your warranty identification, your name and new mailing address. Mail to:

YAMAHA MOTOR CORPORATION, U.S.A.
WARRANTY DEPARTMENT
P.O.Box 6555
Cypress, California 90630

This will ensure that Yamaha Motor Corporation, U.S.A. has an up-to-date registration record in accordance with federal law.

IMPORTANT WARRANTY INFORMATION IF YOU USE YOUR YAMAHA OUTSIDE U.S.A. OR CANADA

Welcome to the Yamaha Family!

Congratulations on the purchase of your new Yamaha marine power. Yamaha is committed to exceptional customer satisfaction, and we want your ownership experience to be a satisfying one. Please read the following warranty information to help ensure satisfaction with your Yamaha.

This model was manufactured as a U.S.A. specification model, and the warranty statement shown in this manual is for market. To receive the benefits of the warranty that applies to the country in which you use your Yamaha, please note the following information.

1. The warranty on this model is the same as equivalent models sold in the country where you will receive service. If you need more information about your warranty coverage or your Yamaha outside the U.S.A. or Canada, please contact an authorized Yamaha dealer in your country.
2. Keep a copy of your sales contract or invoice for the purchase of your Yamaha and present it if you need warranty repairs. This document should show the date of purchase, which is important evidence the repairing dealer will need to be sure your Yamaha is covered by warranty.
3. If your Yamaha needs warranty repairs, contact an authorized Yamaha dealer in the country where you are. He will explain how to get warranty service in that country.
4. This Yamaha model may not be sold in some countries. Therefore, in some cases your local dealer may not have all the parts or service information he may need, which may unavoidably delay repairs. If this happens, we thank you for your understanding and assure you we will attempt to resolve the situation as quickly as possible.

